JH CRUZE

OWNER'S HANDBOOK

HOLDEN

GM Holden Ltd, ABN 84 006 893 232 (hereinafter Holden)

Change of name, address or ownership

If you drive a pre-owned Holden, have moved house or changed any of your details, we'd like to hear from you!

Holden uses your details to keep your vehicle's factory provided Roadside Assistance and Warranty details up to date.

It also helps us let you know if there is an existing safety recall or rework on your vehicle. To update your details, please take a few minutes to fill in and mail the form at the back of the Service/Warranty booklet or visit Holden's website at: www.holden.com.au/forms/change-of-owner-details

GM Holden Ltd (Holden) is collecting the new owner's personal information in order to process the request for transfer for the specified vehicle. We may disclose your personal information to our related companies and third parties who provide us with (or help us provide) products and services, including to overseas locations such as the USA, and other countries in Europe, Oceania and Asia. Holden's privacy policy (available at: www.holden.com.au/privacypolicy) states how you can seek to access or correct any personal information Holden holds about you, how to complain about a privacy breach by Holden and how Holden will deal with a privacy complaint.
You can contact Holden on 1800 033 349 or alternatively, you may prefer to email Holden at: holdencustomercare@gm.com

Note: Please refer to the inside front cover of the Service/Warranty booklet for the Vehicle Identification Certificate.

Printed in Australia
Part No. 92458650
May 2015
(MY15 JH Cruze. Print 2)

© 2015 GM Holden Ltd
Reproduction in whole or part is
prohibited without written approval from
GM Holden Ltd, ABN 84 006 893 232

Contents

Introduction 2
In brief 4
Keys, doors and windows 19
Seats, restraints 34
Storage 50
Instruments and controls 59
Lighting 79
Climate control 84
Driving and operating 93
Vehicle care 118
Service and maintenance 158
Technical data 161
Customer information 172
Index 174

Introduction

We thank you for choosing Holden and want to assure you of our continuing interest in your driving pleasure and satisfaction.

This handbook applies to the current Cruze model. Therefore, due to different models and options, you may find reference in this Handbook to some equipment not fitted to your own vehicle.

Please note that all information, illustrations and specifications in this Handbook are based on the latest production information available at the time of printing. Holden reserves the right to make changes at any time without notice and without incurring any obligation.

Introduction

Your vehicle is a designed combination of advanced technology, safety, environmental friendliness and economy.

This Owner's Manual provides you with all the necessary information to enable you to drive your vehicle safely and efficiently.

Make sure your passengers are aware of the possible risk of accident and injury which may result from improper use of the vehicle.

Using this manual

- The "In brief" section will give you an initial overview.
- The table of contents at the beginning of this manual and within each chapter shows where the information is located.
- The index will enable you to search for specific information.
- Directional data, e.g. left or right, or front or back, always relate to the direction of travel.
- Depending on the model variant, integrated special equipment and accessories, the scope of equipment of your vehicle can differ from the descriptions in this Owner's Manual.
- iPod® is a registered trademark of Apple Inc.
- Zune® is a registered trademark of Microsoft Corporation.

Danger, Warnings and Cautions

⚠Danger

Text marked ⚠**Danger** provides information on risk of fatal injury. Disregarding this information may endanger life.

⚠Warning

Text marked ⚠**Warning** provides information on risk of accident or injury. Disregarding this information may lead to injury.

Caution

Text marked **Caution** provides information on possible damage to the vehicle. Disregarding this information may lead to vehicle damage.

Symbols

Page references are indicated with ⇨. ⇨ means "see page".

In brief

Initial drive information

Vehicle unlocking

Radio remote control

Press button to unlock the doors and boot compartment. Open the doors by pulling the handles, to open the boot compartment, press the button under the boot lid moulding.

Press button, only the boot lid is unlocked and opens.

Remote control ⇨ 19, Central locking system ⇨ 22, Load compartment ⇨ 26.

Electronic key

When in possession of the electronic key, press switch on door handle to unlock the vehicle and pull the door handle to open the door. To open the boot lid, press the button under the moulding.

Electronic key system ⇨ 20.

Seat adjustment

⚠Warning

Only drive with the seat correctly adjusted.

Seat positioning



Pull handle, slide seat, release handle. Try to move the seat back and forth to ensure that the seat is locked in place.

Seat adjustment ⇨ 36, Seat position ⇨ 35.

Seat backrests



Pull lever, adjust inclination and release lever. Allow the seat to engage audibly. Do not lean on backrest when adjusting.

Seat adjustment ⇨ 36, Seat position ⇨ 35.

Seat height



Lever pumping motion

up = higher
down = lower

Seats ⇨ 36, Seat position ⇨ 35.

Head restraint adjustment



For height adjustment, pull the head restraint upward. To move down press the catch and push the head restraint downwards.



For horizontal adjustment, pull the head restraint forward, it engages in 3 positions. To bring into rear position automatically, pull head restraint close forward.

Head restraints ⇨ 34.

Seat belt

Pull out the seat belt and engage in belt buckle. The seat belt must not be twisted and must fit close against the body. The backrest must not be tilted back too far (maximum approx. 25°).

To release belt, press red button on belt buckle.

Seat belts ⇨ 38, Airbag system ⇨ 42, Seat position ⇨ 35.

Mirror adjustment

Interior mirror

Adjust the lever on the underside to reduce glare.

Interior mirror ⇨ 30.

Exterior mirrors

Select the relevant exterior mirror and adjust.

Electric adjustment ⇨ 29, Convex exterior mirrors ⇨ 29, Folding exterior mirrors ⇨ 29, Heated exterior mirrors ⇨ 30.

Steering wheel adjustment

Unlock lever, adjust steering wheel, then engage lever and ensure it is fully locked. Do not adjust steering wheel unless vehicle is stationary and steering wheel lock has been released.

Airbag system ⇨ 42, Ignition positions ⇨ 94.

Instrument panel overview



1 Light switch 79
Front fog lights 81
Instrument illumination 82
2 Side air vents 90
3 Windscreen wipers, windscreen washer system, rear wiper, rear washer system 60
4 Speedometer 64
5 Horn 60
Driver's airbag 42
6 Driver Information Centre 71
7 Steering wheel control for Infotainment system 59
8 Turn signals, headlight flash, low beam and high beam 81
Exit lighting 83
Driver Information Centre 71
9 Centre air vents 90
10 Infotainment system
11 Info-Display 72
12 Storage 50
13 Front passenger airbag 42
14 Glovebox 51
15 Climate control system 84
16 Traction control system 104
Electronic Stability Control . 105
17 Shift lever, automatic transmission 98
Manual transmission 102
18 Hazard warning flashers 80
19 Central locking system 22
20 Accelerator pedal 93
21 Brake pedal 103
22 Ignition switch with steering wheel lock 94
23 Clutch pedal 93
24 Steering wheel adjustment . . 59
25 Cruise Control 106
26 Storage compartment 50
27 Bonnet release lever 119
28 Internal fuse compartment . . 139
29 Start/Stop button, Electronic key system 20
30 Anti-theft alarm system status LED 27

Exterior lighting



Turn

AUTO = Automatic light control: Headlights are switched on and off automatically depending on external light conditions.

⏻ = activation or deactivation of the automatic light control, switch turns back to **AUTO**

≡D = parking lights

≡D = headlights and parking lights

Press

≢D = front fog lights (If fitted)

Lighting ⇨ 79.

Headlight flash, high beam and low beam



headlight flash = pull lever
high beam = push lever
low beam = pull lever from high beam position

High beam ⇨ 80, Headlight flash ⇨ 80, Automatic light control ⇨ 79.

Turn and lane-change signals



left = lever up
right = lever down

Turn and lane-change signals ⇨ 81.

Hazard warning flashers

Operated with the ⚠ button.

Hazard warning flashers ⇨ 80.

Horn

Press .

Washer and wiper systems

Windscreen wipers



1x = single wipe
OFF = off
INT = intermittent operation
LO = continuous wipe, slow speed
HI = continuous wipe, fast speed

For a single swipe when the windscreen wipers are off, push the lever up.

Windscreen wipers ⇨ 60, Wiper replacement ⇨ 127.

Windscreen washer system



Pull lever.

Windscreen washer system ⇨ 60, Washer fluid ⇨ 126.

Rear window wiper and washer systems



Press the rocker switch to activate the rear window wiper:

upper position = intermittent operation
lower position = continuous operation
middle position = off

Rear window wiper/washer ⇨ 61.



Push lever.

Washer fluid is sprayed on the rear window and the wiper wipes a few times.

Climate control

Heated rear window, heated exterior mirrors

Air conditioning system (if fitted)

Electronic climate control system (if fitted)

Heating is operated by pressing the button.

Heated rear window ⇨ 32.

Climate control ⇨ 84.

Demisting and defrosting the windows

Press button .

Set temperature control to warmest level.

Cooling on.

Heated rear window on.

Climate control system ⇨ 84.

Transmission

Manual transmission



Reverse: when the vehicle is stationary, depress the clutch pedal and then pull up the ring on the shift lever and engage the gear.

If the gear does not engage, set the lever in neutral, release the clutch pedal and depress again; then repeat gear selection.

Manual transmission ⇨ 102.

Automatic transmission

P = park
R = reverse
N = neutral
D = drive

Sport mode: move shift lever from **D** to the left.

Manual mode: move shift lever from **D** to the left and then forwards or backwards.

+ = higher gear
− = lower gear

The shift lever can only be moved out of **P** when the ignition is on and the brake pedal is applied. To engage **P** or **R**, push the release button.

Automatic transmission ⇨ 98.

Starting off

Check before starting off

- Tyre pressure and condition ⇨ 141.
- Engine oil level and fluid levels ⇨ 123.
- All windows, mirrors, exterior lighting and number plates are free from dirt, snow and ice and operational.
- Proper position of seats, seat belts and mirrors ⇨ 35, ⇨ 40, ⇨ 29.
- Check brake function at low speed, particularly if the brakes are wet.

Starting the engine



- Turn key to position 1.
- Move the steering wheel slightly to release the steering wheel lock.
- Manual transmission: operate clutch.
- Automatic transmission: operate brake and move shift lever in **P** or **N**.
- Do not accelerate.
- Turn key to position **3** and release when engine is running.

Before restarting or to switch off the engine, turn key back to **0**.

Starting engine with the Start/Stop button



- The electronic key must be inside the vehicle.
- Manual transmission: depress the clutch pedal.
- Automatic transmission: depress the brake pedal and move the shift lever to **P** or **N**.
- Do not accelerate.
- Press the Start/Stop button. The green LED will illuminate.

To switch off the engine, press the button again whilst the engine is running.

Starting the engine ⇨ 94.

Remote Start (if fitted)

- Aim the radio remote control at the vehicle.
- Press and release 🔓.
- Immediately after previous step, press and hold ↺ for at least two seconds or until the turn signal lamps flash.
- The engine will start, doors will be locked and the climate control system may come on.
- The engine will continue to run for 10 minutes. Repeat the steps to extend to 20 minutes. Remote start can be extended only once.
- If the engine is running when you enter the vehicle, press the brake pedal and press the engine Start/Stop button before moving the shift lever out of **P**.

Parking

- Always apply parking brake without pressing release button. Apply as firmly as possible on a downhill slope or uphill slope. Operate foot brake at same time to reduce operating force.
- Switch off the engine and ignition. Turn the ignition key to 0, remove and turn the steering wheel until the steering wheel lock is felt to engage. Vehicles with electronic key system: with the vehicle stationary, press the **Start/Stop** button and open the driver's door.

  For vehicles with automatic transmission, move shift lever to **P** position and remove key.
- If the vehicle is on a level surface or uphill slope, engage first gear (for vehicles fitted with manual transmission) or set the shift lever to **P** (for vehicles fitted with automatic transmission) before switching off the ignition. On an uphill slope, turn the front wheels away from the kerb.

If the vehicle is on a downhill slope, engage reverse gear or set the shift lever to **P** before switching off the ignition. Turn the front wheels towards the kerb.

- Close windows.
- Lock the vehicle with button on the remote control or, for vehicles with electronic key system, press switch on the door handle.

  Keys, locks ⇨ 19.
- Activate the anti-theft alarm system ⇨ 27.
- Do not park the vehicle on an easily flammable surface. The high temperature of the exhaust system could ignite the surface.
- The engine cooling fans may run after the engine has been switched off ⇨ 119.

Keys, doors and windows

Keys, locks 19
Doors 26
Vehicle security 27
Exterior mirrors 29
Interior mirrors 30
Windows 31

Keys, locks

Keys

Replacement keys

The key number is specified on a detachable tag.

Locks ⇨ 155.

Key with foldaway key section

Press button to extend. To fold the key, first press the button.

Remote control

Used to operate:

- Central locking system ⇨ 22
- Anti-theft alarm system ⇨ 27
- Load compartment ⇨ 26
- Remote engine start
- Vehicle location/Panic alarm

The remote control has a range of approx. 25 metres. This range can be affected by outside influences.

The hazard warning flashers confirm operation.

Handle with care, protect it from moisture and high temperatures and avoid unnecessary operation.

Remote engine start (if fitted)

The engine can be started from the outside by pressing button ↺ on the remote control ⇨ 94.

Vehicle location/Panic alarm (if fitted)

To locate the vehicle, press ⇶ briefly. The exterior lamps will flash and the horn will chirp.

In an emergency, press and hold ⇶ for at least 2 seconds. The horn will sound and the turn signals will flash. To cancel, press ⇶ or turn the ignition on.

Fault

If the central locking system cannot be operated with the radio remote control, it may be due to the following:

- Range exceeded,
- Battery voltage too low,
- Frequent, repeated operation of the remote control while not in range, which will require resynchronisation,
- Overloading the central locking by operating at frequent intervals, the power supply is interrupted for a short time,
- Interference from higher-power radio waves from other sources.

Opening the vehicle ⇨ 22.

Remote control battery replacement

Replace the battery as soon as the range reduces, or as per the service schedule.



Extend the key and open the unit. Replace the battery (battery type CR 2032), paying attention to the installation position. Close the unit and synchronise.

Remote control synchronisation

After replacing the battery, unlock the door with the key in the lock. The remote control will be synchronised when you switch on the ignition.

Electronic key system

(If fitted)



Makes operation of the following possible without the use of the mechanical key.

- Central locking system
- Anti-theft alarm system
- Ignition and starter

The electronic key simply needs to be on the driver's person.

Note
Do not put the electronic key in the boot or in front of the Info-Display.

Starting the engine ⇨ 94.

Remote control

The electronic key also has a remote control feature.

Replacing battery in electronic key

Replace the battery as soon as the system no longer operates properly or the range is reduced. The need for battery replacement is indicated by an error code in the Driver Information Centre ⇨ 73.

Batteries do not belong in household waste. They must be disposed of at an appropriate recycling collection point.

Remote control battery replacement ⇨ 19.

Replace the battery (battery type CR 2032), noting the installation position. Engage caps.

Remote control synchronisation

The remote control synchronises itself automatically during every starting procedure.

Fault

If the central locking cannot be operated or the engine cannot be started, the messages **No Remote Detected** or **No Remote Detected. Press Brake to Restart** may be displayed on the Driver Information Centre (DIC). The cause may be one of the following:

- Fault in remote control,
- Electronic key out of reception range,

- Battery voltage too low,
- Interference from higher-power radio waves from other sources.

Try repositioning the electronic key or follow the electronic key manual override ⇨ 94.

Central locking system

Unlocks and locks doors, boot and fuel filler flap.

A pull on an interior door handle unlocks and opens the door.

Note
In the event of an accident of a certain severity, the vehicle unlocks automatically.

Unlocking

Remote control

Press button.

It is configurable to unlock only the driver's door, fuel filler flap and boot by pressing button once and to unlock all by pressing button twice.

Settings can be changed in the menu **Vehicle Settings** in the Info-Display. Vehicle personalisation ⇨ 76.

Electronic key system

Press switch on a door handle to unlock the vehicle and pull the door handle to open the door, or press the button under the boot lid moulding.

The electronic key must be outside the vehicle within a range of approximately one metre of the relevant door side.

It is configurable to unlock only the driver's door or all doors.

Settings can be changed in the menu **Vehicle Settings** in the Info-Display. Vehicle personalisation ⇨ 76.

Locking

Remote control

Close doors, boot and fuel filler flap.

Press button.

If the driver's door is not closed properly, the central locking system will not work on driver's door. Activation or deactivation of the remote control is listed in the menu **Vehicle Settings** in the Info-Display. Vehicle personalisation ⇨ 76.

Electronic key system



Press the switch on a door handle.

The electronic key must be outside the vehicle, within a range of approximately one metre to the relevant door. The spare electronic key must not be inside the vehicle.

It is possible to check that the vehicle is locked by pulling the handle without pressing the button.

Note

The vehicle is not automatically locked.

Unlocking the boot lid

5 Door hatchback, Sportwagon

Press button once or twice, depending on the selected setting. The tailgate will unlock.

Vehicle personalisation ⇨ 76.

4 Door sedan

Press button . The boot lid will unlock and open, whilst all other doors remain locked.

Central locking buttons

Locks or unlocks all doors, the load compartment and fuel filler flap.

Press the button to lock.

Press the button to unlock.

Fault in remote control system or electronic key system

Unlocking

Manually unlock the driver's door by turning the key in the lock. Switch on the ignition and press the central locking button to unlock all doors, boot and fuel filler flap. To deactivate the anti-theft locking system, switch on the ignition.

Locking

Switch on the ignition and press the central locking button to lock the doors, boot and fuel filler flap. Then

switch off the ignition, close the driver's door and lock it from the outside with the key.

Fault in central locking system

Unlocking

Manually unlock the driver's door by turning the key in the door barrel. The other doors can be opened by using the interior handle twice. The fuel filler flap cannot be opened. To deactivate the anti-theft locking system, switch on the ignition.

Locking

Push inside locking knob of all doors except driver's door. Then close the driver's door and lock it from the outside with the key. The fuel filler flap cannot be locked.

Automatic Door Locks

Automatic locking after driving off

This security feature can be configured to automatically lock all doors, boot and fuel filler flap as soon as the vehicle starts to drive.

Settings can be changed in the menu **Vehicle Settings** in the Info-Display. Vehicle personalisation ⇨ 76.

Child locks

⚠Warning

Use the child locks whenever children are occupying the rear seats.

Using a key or suitable screwdriver, turn the child locks in the rear doors into horizontal position. Doors cannot be opened from inside. For deactivation turn the child locks into vertical position.

Doors

Boot

Opening

5 Door hatchback, Sportwagon



After unlocking, push the button below the handle and open the tailgate.

4 Door sedan

Push the button under the boot lid moulding or press button on the remote control until boot lid is opened.

⚠Danger

Do not drive with the boot lid open or ajar, e.g. when transporting bulky objects, since toxic exhaust gases could enter the vehicle.

Caution

Before opening the boot lid check overhead obstructions, such as a garage door, to avoid damage of the boot lid. Always check the moving area above and behind the boot lid.

Note
The installation of certain heavy accessories onto the boot lid may affect its ability to remain open.

Closing

5 Door hatchback

Use the interior handle.

4 Door sedan
Push the boot lid down until it latches.

Sportwagon
Lower the tailgate and push to close.

Vehicle security

Anti-theft alarm system

Anti theft alarm system monitors:

- Doors, boot lid, bonnet
- Passenger compartment including adjoining boot
- Vehicle inclination, e.g. if it is raised
- Ignition

Activation

- Self-activated 30 seconds after locking the vehicle (initialisation of the system), or
- Remote control: directly by pressing once more after locking, or
- Electronic key system: press on the key, after pressing the switch in the door handle to lock.

Note
Changes to the vehicle interior such as open windows or the use of seat covers could impair the function of passenger compartment monitoring.

Status LED

Status LED is integrated in the sensor on top of the instrument panel.

Status during the first 30 seconds of anti-theft alarm system activation:

LED illuminates = test, arming delay.
LED flashes quickly = doors, boot lid or bonnet not completely closed, or system fault.

Status after system is armed:

LED flashes slowly = system is armed.

Seek the assistance of a workshop in the event of faults.

Deactivation

Unlocking the vehicle by pressing button deactivates anti-theft alarm system.

Vehicles with electronic key system: Pressing the switch on a door handle deactivates anti-theft alarm system when the key is within approximately one metre of the relevant door.

Alarm

When triggered, the alarm sounds via a separate battery-backed power sounder, and the hazard warning lights flash simultaneously. The number and duration of alarm signals are stipulated by legislation.

The alarm can be silenced by pressing any button of the remote control or by switching on the ignition.

The anti-theft alarm system can be deactivated only by pressing the button , by pressing the switch on a door handle (only electronic key system) or by switching on the ignition.

Immobiliser

The system is integrated into the ignition switch and checks whether the vehicle is allowed to start with the key being used. If the transponder in the key is recognised, the vehicle can be started.

The immobiliser activates itself automatically after the key has been removed from the ignition switch or when the engine is switched off by pressing the Start/Stop button.

If the control indicator flashes or illuminates when the ignition is on, there is a fault in the system; the engine cannot be started. Switch off the ignition and then repeat the start attempt.

If the control indicator continues flashing, attempt to start the engine using the spare key and seek the assistance of your Holden Dealer.

Note
The immobiliser does not lock the doors. You should always lock the vehicle after leaving it.

Control indicator ▷ 70.

Exterior mirrors

Convex Mirrors

The convex exterior mirror reduces blind spots. The shape of the mirror makes objects appear smaller, which will affect the ability to estimate distances.

Power Mirrors

Select the relevant exterior mirror by turning the control to left **(L)** or right **(R)**. In position **0** no mirror is selected.

Then swivel the control to adjust the mirror.

Folding Mirrors

For pedestrian safety, the exterior mirrors will swing out of their normal mounting position if they are struck with sufficient force. Reposition the mirror by applying slight pressure to the mirror housing.

Heated mirrors

Air conditioning system (if fitted)

Electronic climate control system (if fitted)

Operated by pressing the button.

Heating works with the engine running and is switched off automatically after a short time.

Interior mirrors

Manual Rearview Mirror

To reduce glare, pull the lever on the underside of the mirror housing.

Windows

Power windows

⚠Warning

Take care when operating the power windows. Risk of injury, particularly to children.

If there are children on the rear seat, switch on the child safety system for the power windows.

Keep a close watch on the windows when closing them. Ensure that nothing becomes trapped in them as they move.

Power windows can be operated

- with ignition on,
- within 10 minutes after switching ignition off,
- if any door is opened within 45 seconds from the ignition being turned off, the windows remain operational for 45 seconds.

Operate the switch for the respective window by pushing to open or pulling to close.

Operation of driver's window

Pushing or pulling lightly to the first detent: window moves down or up as long as switch is operated.

Pushing or pulling further to the second detent and then releasing: window moves down or up automatically with safety function. To stop movement, operate the switch once more in the same direction.

Operation of passenger's window and rear windows

Pushing or pulling lightly to the first detent: window moves down or up as long as switch is operated.

Pushing further to the second detent and then releasing: window moves down automatically. To stop movement, operate the switch once more in the same direction.

Safety function on driver's window

If the window glass encounters resistance above the middle of the window during automatic closing, it is immediately stopped and opened again.

Safety function all doors

In the event of closing difficulties due to frost or the like, hold the switch pulled. The window moves up without activating the safety function. To stop movement, release and operate the switch once more in the same direction.

Child safety system for rear windows

Press switch to deactivate rear door power windows, the LED lights up. To activate press again.

Overload

If the windows are repeatedly operated within short intervals, the window operation is disabled for some time.

Initialising the power windows

If the windows cannot be closed automatically (e.g. after disconnecting the vehicle battery), a warning message or a warning code is displayed in the Driver Information Centre.

Vehicle messages ⇨ 73.

Activate the window electronics as follows:

1. Close doors.
2. Switch on ignition.
3. Close the window completely and keep the switch pulled for additional 2 seconds.
4. Repeat for each window.

Heated rear window

Air conditioning system (if fitted)

Electronic climate control system (if fitted)

Operated by pressing the button.

Heating works with the engine running and is switched off automatically after a short time.

Sun visors

The sun visors can be folded down or swivelled to the side to prevent glare.

If the sun visors have integral mirrors, the mirror covers should be closed when driving.

Seats, restraints

Head restraints 34
Front seats 35
Rear seats 38
Seat belts 38
Airbag system 42
Child restraints 45

Head restraints

Position

⚠Warning

Only drive with the head restraint set to the proper position.



The upper edge of the head restraint should be at upper head level. If this is not possible for extremely tall people, set to highest position, and set to lowest position for small people.

Head restraints on front seats

Height adjustment



Pull the head restraint upwards.

To move down press the catch and push the head restraint downwards.



Horizontal adjustment

To adjust horizontally, pull the head restraint forwards and engage in one of three positions.

To return to its rearmost position, pull fully forwards and release.

Head restraints on rear seats

Height adjustment



Pull the head restraint upwards.

To move down press the catch and push the head restraint downwards.

Front seats

Seat position

⚠Warning

Only drive with the seat correctly adjusted.

- Sit with your buttocks as far back against the backrest as possible. Adjust the distance between the seat and the pedals so that your legs are slightly angled when

applying the pedals. Slide the passenger seat as far back as possible.

- Sit with your shoulders as far back against the backrest as possible. Set the backrest rake so that you can easily reach the steering wheel with your arms slightly bent. Maintain contact between your shoulders and the backrest when turning the steering wheel. Do not angle the backrest too far back. We recommend a maximum rake of approx. 25°.
- Adjust the steering wheel ⇨ 59.
- Set seat height high enough to have a clear field of vision on all sides and of all display instruments. There should be at least one hand of clearance between your head and the headlining. Your thighs should rest lightly on the seat without pressing into it.
- Adjust the head restraint ⇨ 34.
- Adjust the height of the seat belt ⇨ 40.

Seat adjustment

⚠ Danger

Do not sit nearer than 25 cm from the steering wheel, to permit safe airbag deployment.

⚠ Warning

Never adjust seats while driving as they could move uncontrollably.

Seat positioning



Pull handle, slide seat, release handle. Try to move the seat back and forth to ensure that the seat is locked in place.

Seat backrests



Pull lever, adjust inclination and release lever. Allow the seat to

Do not lean on seat when adjusting.

Seat height



Lever pumping motion

up = higher
down = lower

Armrest

Armrest between front seats

Push button on the front edge and fold armrest upward. The open armrest contains a stowage compartment.

Horizontal adjustment



Push button to slide the armrest.

Heated Front Seats

(if fitted)

Activate front seat heating (while the engine is running) by pressing the button in the control knob for temperature (left seat) or fan speed (right seat) one or more times with the ignition on. The number of LEDs in the button indicates the setting.

Prolonged use of the highest level for people with sensitive skin is not recommended.

Seat heating is operational when the engine is running.

Remote start heated seats

The vehicle may have heated seats that can be automatically turned on during a remote start, when the temperature outside is below approximately 10 degrees. They are cancelled when the ignition is turned on.

Press the button to use the heated seats after the vehicle is started.

The heated seat indicator lights do not turn on during a remote start.

The temperature performance of an unoccupied seat may be reduced. This is normal.

The heated seats will not turn on during a remote start unless they are enabled in the vehicle personalisation menu.

Remote vehicle start ⇨ 94, vehicle personalisation ⇨ 76.

Rear seats

Armrest

Fold armrest down by pulling the strap. The folded armrest contains drink holders.

Seat belts

Seat belt reminder for driver's seat and front passenger seat, seat belt control indicator ⇨ 67.

The belts are locked during heavy acceleration or deceleration of the vehicle for the safety of the occupants.

⚠Danger

Fasten seat belt before each trip.

In the event of an accident, people not wearing seat belts endanger their fellow occupants and themselves.

⚠Warning

Seatbelts are designed to bear upon the bony structure of the body, and should be worn low across the front of the pelvis or the pelvis, chest and shoulders, as applicable; wearing the lap section of the belt across the abdominal area must be avoided.

Seatbelts should be adjusted as firmly as possible, consistent with comfort, to provide the protection for which they have been designed. A slack belt will greatly reduce the protection afforded to the wearer.

Care should be taken to avoid contamination of the webbing with polishes, oils and chemicals, and particularly battery acid. Cleaning may safely be carried out using mild soap and water. The belt should be replaced if webbing becomes frayed, contaminated or damaged.

It is essential to replace the entire assembly after it has been worn in a severe impact even if damage to the assembly is not obvious.

Belts should not be worn with straps twisted.

Each belt assembly must only be used by one occupant; it is dangerous to put a belt around a child being carried on the occupant's lap.

No modifications or additions should be made by the user which will either prevent the seatbelt adjusting devices from operating to remove slack, or prevent the seatbelt assembly from being adjusted to remove slack.

Periodically check all parts of the belt system for damage, soiling and proper functionality.

Have damaged components replaced. After an accident, have the belts and triggered belt tensioners replaced by your Holden Dealer.

Note

Make sure that the belts are not damaged by shoes or sharp-edged objects or trapped. Prevent dirt from getting into the belt retractors.

Belt force limiters

In the front seats, stress on the body is reduced by dampened release of the belt during a collision.

Belt tensioners

In the event of a head-on or rear-end collision of a certain severity, the front seat belts are tightened.

⚠Warning

Incorrect handling (e.g. removal or fitting of belts or belt buckles) can trigger the belt tensioners with risk of injury.

Deployment of the belt tensioners is indicated by illumination of control indicator ⇨ 67.

Triggered belt tensioners must be replaced by your Holden Dealer. Belt tensioners can only be triggered once.

Note

Do not affix or install accessories or other objects that may interfere with the operation of the belt tensioners. Do not make any modifications to belt tensioner components as this will invalidate the vehicle type approval.

Three-point seat belt

Fitting

Withdraw belt from reel, guide it untwisted across the body and engage the latch plate in the buckle. Tension the lap belt regularly whilst driving by tugging the shoulder belt.

Loose or bulky clothing prevents the belt from fitting snugly. Do not place objects such as handbags or mobile phones between the belt and your body.

⚠Warning

The belt must not rest against hard or fragile objects in the pockets of your clothing.

Height adjustment



1. Pull belt out slightly.
2. Press button.
3. Adjust height and engage.

Adjust the height so that the belt lies across the shoulder. It must not lie across the throat or upper arm.

Do not adjust while driving.

Removing

To release belt, press red button on belt buckle.

Seat belts on the rear seats

The three point seat belt for the rear centre seat can only be withdrawn from the retractor if the backrest is in the rear position.

Pregnant women

Seat belts work for everyone, including pregnant women. Like all occupants, they are more likely to be seriously injured if they do not wear a seatbelt. A pregnant woman should wear a three point seat belt with the lap portion of the belt worn as low as possible below the rounding of their stomach, throughout the pregnancy.

Airbag system

The airbag system consists of a number of individual systems.

When triggered the airbags inflate within milliseconds. They also deflate so quickly that it is often unnoticeable during the collision.

⚠Warning

If handled improperly the airbag systems can be triggered in an explosive manner.

Note

The airbag systems and belt tensioner control electronics are located in the centre console area. Do not put any magnetic objects in this area.

Do not stick anything on the airbag covers and do not cover them with other materials.

Each airbag is triggered only once. Have deployed airbags replaced by a Holden Dealer.

In the event of airbag deployment have the steering wheel, the instrument panel, all panelling parts, the door seals, the handles and the seats replaced by your Holden Dealer.

Control indicator for airbag systems ⇨ 67.

Front airbag system

The front airbag system consists of one airbag in the steering wheel and one in the instrument panel on the passenger side. These can be identified by the word **AIRBAG**.

The front airbag system is triggered in the event of an accident of a certain severity. The ignition must be on.



In the event of an accident (e.g. front end collision) the forward movement of the front seat occupants is retarded, thereby considerably reducing the risk of injury to the upper body and head.

⚠Warning

Optimum protection is only provided when the seat is in the proper position ⇨ 35.

Keep the area in which the airbag inflates clear of obstructions.

Wear the seat belt properly fastened. Only then the airbag is able to protect.



Refer to the airbag warning label on the passenger's sunvisor.

Depending on the body style, a different airbag label may be located on the passenger's sunvisor.

⚠Warning

EXTREME HAZARD!

Do not use a rearward facing child restraint on a seat protected by an airbag in front of it!

The child could be seriously injured if the airbag inflates, as the child's head would be very close to the inflating airbag.

Side airbag system



The side airbag system consists of an airbag in each front seat backrest. This can be identified by the word **AIRBAG**.

The side airbag system is triggered in the event of an accident of a certain severity. The ignition must be on.



The risk of injury to the upper body and pelvis in the event of a side-on collision is considerably reduced.

⚠Warning

Keep the area in which the airbag inflates clear of obstructions.

Note
Only use protective seat covers that have been approved for your vehicle. Be careful not to cover the airbags.

Curtain airbag system

The curtain airbag system consists of an airbag in the roof frame on each side. This can be identified by the word **AIRBAG** on the roof pillars.

The curtain airbag system is triggered in the event of an accident of a certain severity. The ignition must be on.



The risk of injury to the head in the event of a side impact is considerably reduced.

⚠Warning

Keep the area in which the airbag inflates clear of obstructions.

The hooks on the handles in the roof frame are only suitable for hanging up light articles of clothing, without coat hangers. Do not keep any items in these clothes.

Child restraints

Child restraint systems

When a child restraint system is being used, pay attention to the following usage and installation instructions and also those supplied with the child restraint system.



Refer to the airbag warning label on the passenger's sunvisor.

Depending on the body style, a different airbag label may be located on the passenger's sunvisor.

⚠Warning

EXTREME HAZARD!

Do not use a rearward facing child restraint on a seat protected by an airbag in front of it!

The child could be seriously injured if the airbag inflates, as the child's head would be very close to the inflating airbag.

⚠Warning

This manual provides you with general information concerning child restraints only. The driver is required by law to ensure that passengers are suitably restrained.

In most States and Territories of Australia and New Zealand, specific laws may exist which require children to be seated in approved child restraints and/or certain locations within the vehicle. Holden strongly

recommends that you refer to your specific State or Territory regulations to determine which child restraint and seat location is suitable for your child.

Children should be restrained at all times when travelling in a vehicle.

Always ensure that the seat belt fits firmly around the child restraint, as applicable to the type of restraint used.

If a child cannot see out of the window, do not raise him/her by means of an ordinary cushion. It will not stay in place in a collision and the child can slip out of the straps and become entangled.

⚠Warning

It is safest for children to be seated in the rear seat.

Only child restraints that have clips to attach to the vehicle's anchorage fitting are to be used.

Earlier types of child restraints may not attach securely to this type of anchor.

Use only Standards Australia and New Zealand approved child restraints and harnesses. You should only purchase a child restraint which carries the appropriate Standards Australia sticker of approval.

Australian States and Territories and New Zealand have laws restricting the seating of children in the front passenger seat. In most jurisdictions, children under 4 years should not be seated in the front passenger seat. Check your local road safety regulations before seating a child in the front seat. Where legally allowable, you may install a forward-facing child restraint in the front seat, but always move the passenger seat as far back as it will go.

Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle.

Always follow the child restraint manufacturer's fitting instructions when installing a child restraint into the vehicle.

Selecting the right system

The rear seats are the safest location to fasten a child restraint system.

Your child should travel facing backwards in the vehicle, until as old as possible. It is appropriate to change the system when the child's head can no longer be properly supported at eye height. The child's cervical vertebrae are still very weak and in an accident they suffer less stress in the semi-prone rearward position than when sitting upright.

Never carry a child whilst travelling in the vehicle. The child will become too heavy to hold in the event of a collision.

When transporting children, use the child restraint systems suitable for the child's weight.

Ensure that the child restraint system to be installed is compatible with the vehicle type.

Ensure that the mounting location of the child restraint system within the vehicle is correct.

Only allow children to enter and exit the vehicle at the side facing away from the traffic.

When the child restraint system is not in use, secure the seat with a seat belt or remove it from the vehicle.

Note

Do not stick anything on the child restraint systems and do not cover them with any other materials.

A child restraint system which has been subjected to stress in an accident must be replaced.

Please ensure that infants and children are seated in the rear seats using child restraints.

Until the children can use seat belts, please select a child restraint suitable for its age and make sure the child wears it. Please see the instructions on the relevant products for child restraints.

Child restraint installation locations

Permissible options for fitting a child restraint system

Weight and age class	On front passenger seat	On rear outboard seats	On rear centre seat
Group 0: up to 10 kg or approx. 10 months	X	U[1]	U
Group 0+: up to 13 kg or approx. 2 years	X	U[1]	U
Group I: 9 to 18 kg or approx. 8 months to 4 years	X	U[1]	U
Group II: 15 to 25 kg or approx. 3 to 7 years	X	U[1]	U
Group III: 22 to 36 kg or approx. 6 to 12 years	X	U[1]	U

U = Universal suitability in conjunction with three-point seat belt.
X = No child restraint system permitted in this weight class.
1 = Seat available with ISOFIX and Top-Tether mounting brackets.

Isofix child restraint systems

Fasten vehicle-approved ISOFIX child restraint systems to the ISOFIX mounting brackets.

Note
Ensure that seat belt buckles are placed out of the way of the child seat.

ISOFIX mounting brackets are indicated by a label on the seat back, see illustration.

In addition to the ISOFIX mounting, fasten the top-tether straps to the top-tether anchorage points. Top-tether child restraint systems ⇨ 49.

Top-tether child restraint systems



Fasten Top-tether child restraint systems to the fastening eyes on the places behind the rear head restraints or on the back of the rear seats.



The strap must run between the two guide rods of the head restraint.

When using Top-tether for seat mounting, universally approved child restraint systems for Top-Tether may be used.

Top-tether mounting loops are indicated by labels on the load compartment cover or on the back of the rear seats.

Front of vehicle - A

Storage

Storage compartments 50
Load compartment 52
Roof rack system 57
Loading information 58

Storage compartments

⚠Warning

Do not store heavy or sharp objects in the storage compartments. Otherwise, the storage compartment lid could open and vehicle occupants could be injured by objects being thrown around in the event of sharp braking, a sudden change in direction or an accident.

Instrument panel storage

Storage on top of the instrument panel

Pull the grip to fold up the cover.

Storage below the light switch

Pull the grip to open the box.

Glovebox

To open pull the grip.

⚠Warning

To reduce the risk of injury in an accident or a sudden stop, always keep the glovebox door closed while driving.

Cupholders



Cupholders are located in the centre console.

Additional cupholders are located in the rear armrest, when it is folded down.

Sunglasses storage

(If fitted)



Fold down to open.

Do not use for storing heavy objects.

Armrest storage

Storage in the front armrest



Push button on the front edge to slide or fold up the armrest.

Load compartment

Folding down rear seat backrests

The rear backrest is divided into two parts. Both parts can be folded down.

Push head restraints down by pressing the catch.

Fold up rear armrest.

Pull release lever on one or both sides and fold down the backrests on the seat cushion.



The seat belts must be pulled out and positioned away from the backrest.

Fold up backrests into upright position.

Latch seat backrests into position by pushing at the upper part of the backrest until they engage audibly.

Pull seat backrests forward again to make sure they are correctly engaged.

The backrests are only engaged when the red marks on both sides near the release lever are not visible.

Insert all safety belts into the slots, if seat belts are not coiled up automatically.

The centre rear safety belt may lock when you raise the seatback. If this happens, let the belt go back all the way and start again.

Never fold seat backrest when the rear centre seat belt is buckled or extracted.

Bag hanger (if fitted)



On the left side in the boot is a retainer for hanging light carrier bags.

Rear storage

On Sportwagon a tray is located behind the rear seats.

Removing tray



Push tray upwards at the front to disengage

Pull tray rearwards and remove.

Installing tray

Engage tray in rear side guides and push tray down at the front to engage.

Load compartment cover

Do not place any objects on the cover.

5 Door hatchback

Removing

Unhook retaining straps from tailgate.



Lift cover at the rear and push it upwards at the front, from underneath.

Remove the cover.

Fitting

Engage cover in side guides and fold downwards. Attach retaining straps to tailgate.

Sportwagon

Closing cover

Pull the cover towards the rear using the handle until it locates in the side retainers. Lift slightly to engage.

Opening cover



Pull the handle at the end of the cover to the rear and downwards. It rolls up automatically.

Cover in upper position



Push the handle at the end of the cover downwards. The rear of the cover is guided upwards automatically.

Removing cover

Open the load compartment cover.

Pull the end of the cover inwards and lift the cover. Remove the cover.

Installing cover

Insert the cover in the side retainer on one side. Lower the cover and engage.

Rear floor storage cover

Rear floor cover, Sportwagon



Unlock the rear floor cover by pushing both catches inwards. Lift the cover by pulling the handle. Fold and place the cover behind the rear seats.

Lashing eyes



The lashing eyes are designed to secure items against slippage, e.g. using lashing straps or luggage net.

Safety net

The safety net is available on the Sportwagon and can be installed behind the rear seats or, if the rear seat backrests are folded, behind the front seats.

Passengers must not be transported behind the safety net.

Installation

Behind the rear seats

Attach lower hook with opening facing backward to eye in the right and left sidewall. Adjust strap length on safety net by attaching the upper hook to the eyes of the strap. Keep strap under tension while proceeding with installation of rod.

Behind the front seats



Attach strap to eyes underneath the rear seat cushion.

Fold backrests forward.

Move front seats forward to ease tension if necessary.

Installation of the rod



There are two installation openings in the roof frame: suspend and engage rod of net at one side, compress rod and suspend and engage at other side.

Load compartment ⇨ 52.

Removal

Unhook the safety net rods from the brackets in the roof frame. Detach straps from the eyes. Roll up the net and secure with a strap.

The removed safety net can be stored under the rear floor cover ⇨ 55.

Roof rack system

Roof rack

For safety reasons and to avoid damage to the roof, the vehicle approved roof rack system is recommended.

Follow the installation instructions and remove the roof rack when not in use.

⚠Warning

For safety reasons, and to avoid damaging the roof, use only the roof rack approved by Holden for your vehicle. The maximum allowable roof load (including the weight of the roof racks) is:

- Sedan, Hatchback: 45 kg
- Sportwagon: 50 kg

Roof rack loads alter the handling of a vehicle due to a change in the centre of gravity.

Avoid abrupt swerving or sharp steering when carrying loads on the roof rack.

Loading information

- Heavy objects in the boot should be placed against the seat backrests. Ensure the backrests are securely engaged. If objects can be stacked, the heavier objects should be placed at the bottom.
- Secure objects in load compartment to prevent sliding.
- Secure objects with lashing straps attached to lashing eyes ⇨ 56.
- When transporting objects in the load compartment, the backrests of the rear seats must not be angled forward.
- Do not allow the load to protrude above the upper edge of the backrests.
- Do not place any objects on the boot lid cover or the instrument panel, do not cover the sensor on top of the instrument panel.
- The load must not obstruct the operation of the pedals, parking brake and shift lever, or hinder the freedom of movement of the driver. Do not place any unsecured objects in the interior.
- Do not drive with an open boot lid.
- Optional equipment and accessories increase the kerb weight.
- Driving with a roof load increases the sensitivity of the vehicle to cross-winds and has a detrimental effect on vehicle handling due to the vehicle's higher centre of gravity. Distribute the load evenly and secure it properly with retaining straps. Adjust the tyre pressure and vehicle speed according to the load conditions. Check and retighten the straps frequently.

Instruments and controls

Controls 59
Warning lights, gauges and indicators 64
Information displays 71
Vehicle messages 73
Trip computer 74
Vehicle personalisation 76

Controls

Steering wheel adjustment

Unlock lever, adjust steering wheel, then engage lever and ensure it is fully locked.

Do not adjust steering wheel unless vehicle is stationary.

Steering wheel controls

The Infotainment system can be operated by the controls on the steering wheel.

For further information, see the Infotainment System Handbook.

Horn

Press .

Windscreen wiper/washer

Windscreen wiper



1x = single wipe
OFF = off
INT = intermittent operation
LO = continuous wipe, slow speed
HI = continuous wipe, fast speed

For a single swipe when the windscreen wipers are off, push the lever up.

Do not use if the windscreen is frozen.

Switch off in car washes.

Adjustable wiper interval



During intermittent operation, adjust the frequency of the wiper intervals:

short interval = turn adjuster wheel downwards
long interval = turn adjuster wheel upwards

Automatic wiping with rain sensor (if fitted)

The rain sensor detects the amount of water on the windscreen and automatically regulates the frequency of the windscreen wiper. After activation of the rain sensor mode or

adjusting the sensitivity of the rain sensor the new setting is confirmed by a single wipe.

= automatic wiping with rain sensor



Turn the adjuster wheel to adjust the sensitivity:

low sensitivity = turn adjuster wheel upwards

high sensitivity = turn adjuster wheel downwards



Keep the sensor free from dust, dirt and ice.

Windscreen washer



Pull lever. Washer fluid is sprayed onto the windscreen and the wiper swipes for a few strokes.

Rear window wiper/washer



Press the rocker switch to activate the rear window wiper:

upper position = intermittent operation

lower position = continuous operation

middle position = off



Push lever. Washer fluid is sprayed on the rear window and the wiper wipes a few times.

Do not use if the rear window is frozen.

Switch off in car washes.

The rear window wiper comes on automatically when the windscreen wiper is switched on and reverse gear is engaged.

Activation or deactivation of this function can be changed in the menu **Vehicle Settings** in the Info-Display.

Vehicle personalisation ⇨ 76.

The rear window washer system is deactivated when the fluid level is low.

Outside temperature



A drop in temperature is indicated immediately and a rise in temperature after a time delay.

Additionally, a warning message may be displayed in the Driver Information Centre if the outside temperature drops to 3 °C, as a warning for icy road conditions.

❄ remains illuminated until temperatures reach at least 5 °C.

⚠Warning

The road surface may already be icy even though the display indicates a few degrees above 3 °C.

Clock

Date and time are shown in the Info-Display.

Colour Information Display (CID)

Set date and time

To set the time:

1. Press **CLOCK**, then rotate and press **MENU SEL** to select **SET TIME**.
2. Select between hours and minutes by pressing the **MENU SEL** knob.
3. Use the **MENU SEL** knob to adjust the Hours and Minutes to decrease and increase the time.
4. Press **BACK** to exit.

To select 12 / 24 hours format:

1. Rotate and press **MENU SEL** to select **12hr / 24hr** format.
2. Rotate and press **MENU SEL** to select either 12 hour or 24 hour.

   A tick indicates the selected format.
3. Press **BACK** to exit.

To set the date:

1. Press **CLOCK**, then rotate and press **MENU SEL** to select **SET DATE**.
2. Select between year, month and day by pressing the **MENU SEL** knob.
3. Use the **MENU SEL** knob to adjust the year, month and day.
4. Press **BACK** to exit.

Vehicle personalisation ⇨ 76.

Power outlets

(If fitted)



12V power outlets are located in the front and rear floor console.

Do not exceed the maximum power consumption of 120 watts.

With ignition off the power outlets are deactivated. Additionally the power outlets are deactivated in case of low battery voltage.

Do not connect any current-delivering accessories, e.g. electrical charging devices or batteries.

Do not damage the sockets by using unsuitable plugs.

Warning lights, gauges and indicators

Speedometer



Indicates vehicle speed.

Note
When driving in the speed limited zones, such as child-safety zones, please keep the speed limits.

Odometer



The bottom line displays the recorded distance.

Different displays are used depending on the model.

Trip odometer

The top line displays the recorded distance since the last reset.

When kilometres are selected as unit in the **Vehicle Information Menu**, the maximum value is **1999.9**. When the recorded distance reaches **2000**, the trip odometer automatically shows **0** without resetting.

Tachometer

Displays the engine revolutions per minute.

Drive in a low engine speed range for each gear as much as possible.

Caution

If the needle is in the red warning zone, the maximum permitted engine speed is exceeded. Engine is at risk.

Fuel gauge

Displays the fuel level in the tank.

Control indicator ⬬ illuminates if the level in the tank is low. Refuel immediately.

Never run the tank dry.

Because of the fuel remaining in the tank, the top-up quantity may be less than the specified tank capacity.

Engine Temperature gauge



Displays the coolant temperature.

left area	=	engine operating temperature not yet reached
central area	=	normal operating temperature
right area	=	temperature too high

Caution

Do not continue driving with the temperature gauge needle in the right area. The engine is too hot. Continued operation of an overheated engine will result in severe engine damage.

Control indicators

The control indicators described are not present in all vehicles. The description applies to all instrument versions. Depending on the equipment, the position of the control indicators may vary. Different displays are used depending on model. When the ignition is switched on, most control indicators will illuminate briefly as a functionality test.

The control indicator colours mean:

red	=	danger, important reminder
yellow	=	warning, information, fault
green	=	confirmation of activation
blue	=	confirmation of activation
white	=	confirmation of activation

Control indicators in the instrument

Turn signal

⇦⇨ illuminates or flashes green.

Flashes

The control indicator flashes if a turn signal or the hazard warning flashers are activated.

Fast flashing: failure of a turn signal light or associated fuse.

Bulb replacement ⇨ 127. Fuses ⇨ 136.

Turn signals ⇨ 81.

Seat belt reminder

Seat belt reminder on front seats

for driver's seat illuminates or flashes red.

2 for front passenger seat illuminates or flashes red, when seat is occupied.

Illuminates

After the ignition is switched on. Illuminates for 100 seconds after starting the engine or reaching a specific distance or speed, or until the seat belt is fastened.

Flashes

Flashes for 100 seconds after starting the engine or reaching a specific distance or speed, or until the seat belt is fastened.

Fastening the seat belt ⇨ 40.

Airbag and belt tensioners

illuminates red.

When the ignition is switched on, the control indicator illuminates for about 4 seconds. If it does not illuminate, does not go out after 4 seconds or illuminates whilst driving, there is a fault in the belt tensioner or in the airbag system. The systems may fail to trigger in the event of an accident.

Deployment of the belt tensioners or airbags is indicated by continuous illumination of .

⚠Warning

Have the cause of the fault remedied immediately by your Holden Dealer.

Airbag system, belt tensioners ⇨ 42, ⇨ 38.

Charging system

illuminates or flashes red.

Illuminates for a few seconds after the ignition is switched on.

Illuminates when the engine is running

Stop, switch off engine. Battery is not charging. Engine cooling may be interrupted. Seek the assistance of your Holden Dealer.

Malfunction Indicator Lamp

illuminates or flashes yellow.

It illuminates when the ignition is switched on and goes out shortly after the engine starts.

If illuminates while driving, there may be a malfunction in the emission monitoring system. Contact a Holden Dealer.

Service vehicle soon

illuminates.

It illuminates in combination with a warning code.

Vehicle messages ⇨ 73.

Brake and clutch system

illuminates red.

Illuminates when the parking brake is actuated if the brake/clutch fluid level is too low or if there is a brake system fault ⇨ 126.

⚠Warning

Stop. Do not continue your journey. Contact your Holden Dealer.

Illuminates after the ignition is switched on if the manual parking brake is applied ⇨ 103.

Antilock brake system (ABS)

illuminates yellow.

Illuminates for a few seconds after the ignition is switched on. The system is ready for operation when the control indicator goes out.

If the control indicator does not go out after a few seconds, or if it illuminates while driving, there is a fault in the ABS. The brake system remains operational but without ABS regulation.

Antilock brake system ⇨ 103.

Power steering

illuminates yellow.

Illuminates with power steering reduced

Power steering is reduced due to overheating of the system. Control indicator goes out when the system has cooled down.

Illuminates with power steering disabled

Failure in the power steering system. Contact your Holden Dealer.

Illuminates after interruption of power supply

The steering angle sensor must be calibrated to make the power steering system operational.

- For automatic calibration, drive in straight line at constant slow speed until the control indicator goes out.
- If the control indicator remains illuminated, turn the steering wheel from limit position to limit position for manual calibration.

The control indicator goes out when the system is operational again.

Ultrasonic parking assist

(If fitted)

P illuminates yellow.

Illuminates for a few seconds after the ignition is switched on.

If the control indicator does not go out after a few seconds, or if it illuminates while driving, there is a fault in the system

or

Fault due to sensors that are dirty or covered by ice or snow

or

Interference due to external sources of ultra sound. Once the source of interference is removed, the system will operate normally.

Have the cause of the fault in the system remedied by your Holden Dealer.

Ultrasonic parking sensors ⇨ 107.

Electronic Stability Control

illuminates or flashes yellow.

Illuminates for a few seconds after the ignition is switched on.

Illuminates

A fault in the system is present. Continued driving is possible. Driving stability, however, may deteriorate depending on road surface conditions.

Have the cause of the fault remedied by your Holden Dealer.

Flashes

The system is active. Engine output may be reduced and the vehicle may be braked automatically to a small degree.

Electronic Stability Control off

illuminates yellow.

Illuminates for a few seconds after the ignition is switched on.

Illuminates when the system is deactivated.

Traction Control system off

illuminates yellow.

Illuminates for a few seconds after the ignition is switched on.

Illuminates when the system is deactivated.

Engine oil pressure

illuminates red.

Illuminates for a few seconds after the ignition is switched on.

Illuminates when the engine is running

Caution
Engine lubrication may be interrupted. This may result in damage to the engine and/or locking of the drive wheels.

1. Depress clutch.
2. Select neutral gear, set shift lever to **N**.
3. Move out of the flow of traffic as quickly as possible without impeding other vehicles.
4. Switch off ignition.

⚠Warning

When the engine is off, considerably more force is needed to brake and steer.

Do not remove key until vehicle has come to a standstill, otherwise the steering column lock could engage unexpectedly.

Check oil level before seeking assistance of your Holden Dealer ⇨ 123.

Low fuel

● illuminates yellow.

Illuminates when level in fuel tank is too low.

Catalytic converter ⇨ 98.

Immobiliser

illuminates or continously flashes yellow.

Illuminates for a few seconds after the ignition is switched on.

Fault in the electronic immobiliser system. The engine cannot be started.

Have the cause of the fault remedied by your Holden Dealer.

Apply footbrake

Press Brake to Start Engine is displayed on the DIC.

Displayed when brake or clutch pedal needs to be depressed to start vehicles with electronic key system ⇨ 20.

Exterior light

illuminates green.

Illuminates when the parking lights are on ⇨ 79.

High beam

illuminates blue.

Illuminates when high beam is on and during headlight flash ⇨ 80.

Fog light

(If fitted)

illuminates green.

Illuminates when the front fog lights are on ⇨ 81.

Cruise control

illuminates white or green.

Illuminates white

The system is on.

Illuminates green

A certain speed is stored.

Cruise control ⇨ 106

Door Ajar Light

illuminates red or white.

It illuminates when a door or the boot lid is open.

Information displays

Driver Information Centre



The Driver Information Centre (DIC) is located in the instrument cluster between speedometer and tachometer.



Different displays are used depending on model.

Selecting functions

The menus and functions can be selected by the buttons on the turn signal lever.

Press the **MENU** button to switch between the menus.

The menu is locked when vehicle is moving.

The following menus can be selected:

- **Vehicle Information**
- **Trip/Fuel Information**

Depending on model, the menus can be selected by symbols in the top line of the display:

- **Vehicle Information**
- **Trip/Fuel Information**

Turn the adjuster wheel to scroll through a menu option or to set a numeric value.

Press the **SET/CLR** button to select a function or to confirm a message.

Vehicle personalisation ⇨ 76.

Trip computer ⇨ 74.

Colour Information Display (CID)

The vehicle has a Colour Information Display (CID). The Display is located in the instrument panel above the faceplate of the Infotainment system.

Note
The Colour Information Display (CID) is a touchscreen.

System Settings, Personalisation ⇨ 76.

The Colour Information Display (CID) indicates:

- time ⇨ 62
- outside temperature ⇨ 62
- date ⇨ 62
- Infotainment system, see the Infotainment system handbook
- navigation (if fitted), see the Infotainment system handbook
- system settings
- settings for vehicle personalisation ⇨ 76

The type of information and how it is displayed depend on the equipment of the vehicle and the settings made.

Selecting menus and settings

Rotate the **MENU SEL** button to scroll through the available setup options, press the **MENU SEL** button to select. Alternatively select by touching the touchscreen.

To exit a menu, press **BACK**.

Vehicle messages

Messages are given via the Driver Information Centre (DIC), the Info-Display or as warning and signal buzzers. Confirm warning messages with the **SET/CLR** button on the turn signal lever.

If necessary seek the assistance of your Holden Dealer.

Vehicle messages on the display



Depending on the model the vehicle messages are displayed as code numbers.

No.	Vehicle message
25	Left front turn indicator failure
26	Left rear turn indicator failure
27	Right front turn indicator failure
28	Right rear turn indicator failure
35	Replace battery in radio remote control
75	Service air conditioner
79	Top up engine oil ⇨ 123
84	Engine power is reduced
89	Service vehicle soon
95	Service airbag



Depending on the model, the vehicle messages may be displayed as text. Follow the instructions given in the messages.

The system displays messages regarding the following topics:

- Fluid levels
- Anti-theft alarm system
- Brakes
- Drive systems
- Ride control systems
- Cruise control
- Object detection systems
- Lighting, bulb replacement

- Wiper/washer system
- Doors, windows
- Remote control
- Seat belts
- Airbag systems
- Engine and transmission
- Battery
- Electronic key system

The vehicle message **No Remote Detected** is displayed when the electronic key system does not detect the presence of the electronic key to start the vehicle.

Warning chimes

When starting the engine or whilst driving

- If seat belt is not fastened.
- If a door or the boot lid is not fully closed when starting off.
- If a certain speed is exceeded with parking brake applied.
- If a warning code appears in the Driver Information Centre.
- If the parking assist detects an object (if fitted).

When the vehicle is parked and/or the driver's door is opened

- When the key is in the ignition switch.
- With parking lights on.

Trip computer

The menus and functions can be selected with the turn signal lever.

Turn the adjuster wheel to select one of the submenus:

- Trip meter
- Average consumption
- Range
- Average speed
- Instantaneous consumption
- Speed

Trip meter

Different displays are used depending on model.



To reset, press the **SET/CLR** button for a few seconds.

Average consumption

Display of average consumption. The measurement can be reset at any time.

To reset, press the **SET/CLR** button for a few seconds.

Range

Range is calculated from current fuel tank content and current consumption. The display shows average values.

After refuelling, the range is updated automatically after a brief delay.

When the fuel level in the tank is low the indicator ⬬ in the fuel gauge illuminates.

Average speed

Display of average speed. The measurement can be reset at any time.

To reset, press the **SET/CLR** button for a few seconds.

Instantaneous consumption

Display of the instantaneous consumption is displayed while the vehicle is moving.

Vehicle personalisation

The vehicle's parameters can be personalised by changing the settings in the Driver Information Centre and in the Info-Display.

Depending on vehicle equipment some of the functions described below might not be available.

Note
The Info-Display and the Driver Information Centre are both locked when the vehicle is moving.

Settings in the Colour-Info-Display

Depending on the Infotainment system, the **CONFIG** button is located in different locations.



The following settings can be selected by pressing **CONFIG**, then scrolling through the setup options by rotating the **MENU SEL** knob and pressing **MENU SEL** to select.

Alternatively select by touching the touchscreen.

- **Languages**
- **Time & Date**
- **Radio Settings**
- **Phone Settings**
- **Navigation Settings (if fitted)**
- **Display Settings**
- **Vehicle Settings**

In the corresponding submenus the following settings can be changed by rotating and pressing the **MENU SEL** knob:

Languages
Only English is available.

Time and Date
Clock ⇨ 62.

Radio Settings
See Infotainment system handbook.

Phone Settings
See Infotainment system handbook.

Navigation Settings (if fitted)
See Infotainment system handbook.

Display Settings
Selectable display settings:

- **Home Page Menu**: See Infotainment system handbook.

- **Rear Camera Option** (if fitted): The rear view camera can be switched on and off. The warning symbols and/or guide lines can also be switched on and off.
- **Display Off**: Switches off the display. Press any button to switch back on.
- **Map Settings** (if fitted): Select optimisation for daylight, darkness, or automatic depending on ambient lighting conditions.

  Speed Limits (if fitted): Select to display speed limits on the map when available.

Vehicle Settings

- **Climate and Air Quality**

  Auto fan speed: Change the default fan speed when in Auto mode (high, medium or low).

  Remote Start Heated Seats: Activate or deactivate seat heating when using remote start on cold days.

  Auto demist: Automatic activation of rear heated window.

- **Comfort and Convenience**

  Chime volume: Change the volume of warning chimes.

  Button Chime: Select to activate audible touchscreen button press feedback.

  Personalisation by Driver: Select to allow settings that are specific to each key or otherwise will remain the same, no matter which key was used to enter and start the vehicle.

  Rear auto wipe in reverse gear (if fitted): Activate or deactivate automatically switching on of the rear window wiper when reverse gear is engaged.

- **Collision Detection Systems**

  Park assist: Activate or deactivate the ultrasonic parking assist.

- **Lighting**

  Vehicle Locator Lights: Activate or deactivate the welcome lighting.

  Exit Lighting: Activate or deactivate and change the duration of exit lighting.

- **Power Door Locks**

  Auto Door Lock: Activate or deactivate the automatic door locking function, to occur after driving off.

- **Remote Lock / Unlock / Start**

  Remote Unlock Feedback: Activate or deactivate flashing the lights whilst unlocking.

  Remote Lock Feedback: Activate or deactivate the lights and horn feedback whilst locking.

  Remote Door Unlock: Change the configuration to unlock only the driver's door or the whole vehicle whilst unlocking.

  Relock Remotely Unlocked Doors: Selection of automatically relocking all doors if the doors are unlocked but not opened, after approximately 3 minutes.

  Passive Door Unlock: Change the configuration to unlock only the driver's door or the whole vehicle whilst unlocking with the Electronic key system and pressing the door button.

Passive Door Lock: Select whether the doors are locked 8 seconds after the key is removed from the vehicle and the doors are shut.

Remote Left in Vehicle Reminder: Activate or deactivate the reminder chimes for left remote control in vehicle (Electronic key system).

- **Return To Factory Settings?**

  Return To Factory Settings: Reset all settings to the default settings.

Lighting

Exterior lighting 79
Interior lighting 82
Lighting features 83

Exterior lighting

Light switch



Turn light switch:

AUTO = Automatic light control: Headlights are switched on and off automatically depending on external lighting conditions.

⏻ = Activation or deactivation of the automatic light control. Switch turns back to **AUTO**.

≫⋐ = Parking lights

≣D = Headlights and parking lights

When switching on ignition, automatic light control is always active.

When lights are on, ≫⋐ lights up. Control indicator ≫⋐ ⇨ 70.

Automatic light control



Automatic light control function

When the automatic light control function is switched on and the engine is running, the system switches the headlights and taillights on and off according to ambient light conditions.

Automatic headlight activation
During poor lighting conditions the headlights and taillights are switched on.

Furthermore the headlights are switched on if the windscreen wipers have been activated for several wipes.

High beam



To switch from low to high beam, push lever.

To switch to low beam, push lever again or pull.

⚠Warning

Always switch the high beam headlamps to low beam when you approach oncoming vehicles or when other vehicles ahead. High beam headlamps can temporarily blind other drivers, which could result in a collision.

Headlight flash

To activate the headlight flash, pull lever.

Daytime running lights

The Daytime Running Lights (DRL) illuminate when the following occur:

- During daylight conditions
- The engine is running
- The fog lamps are off

Note
If the light switch is turned to ≡D or ≡D, the DRL will dim to parking lights brightness. The DRL will turn on in night time conditions if the automatic light control function is turned off.

Hazard warning flashers

Operated with the ⚠ button.

The hazard warning flashers activate automatically if the airbags deploy.

Turn and lane-change signals



lever up = left indicator
lever down = right indicator

If the lever is moved past the resistance point, the indicator is switched on constantly. When the steering wheel moves back, the indicator is automatically deactivated.

For three flashes, e.g. when changing lanes, press the lever until resistance is felt and then release.

Move the lever to the resistance point and hold for longer indication.

Switch the indicator off manually by moving the lever to its original position.

Front fog lights

(If fitted)



Operated with the ≠D button.

Reversing lights

The reversing lights come on when the ignition is on and reverse gear is selected.

Misted light covers

The inside of the light housing may mist up briefly in poor, wet and cold weather conditions, in heavy rain or after washing. The mist disappears quickly by itself; to help switch on the headlights.

Interior lighting

Instrument panel illumination control



Brightness of the following lights can be adjusted when the exterior lights are on:

- Instrument panel illumination
- Steering wheel controls
- Info-Display
- Climate control operation elements
- Illuminated switches

Turn knob and hold until the desired brightness is obtained.

Interior lights

Courtesy light



During entry and exit of the vehicle, the courtesy lights automatically switch on and then off after a delay. They switch on for a short time even if the key is withdrawn from the ignition lock.

Operate rocker switch:

= automatic switching on and off
press = always on
press = always off

Reading lights

Operated with and buttons.

Lighting features

Entry lighting

Welcome lighting

Headlights, tail lights and interior lights illuminate for a short time when unlocking the vehicle with the remote control. This function facilitates retrieving the vehicle when it is dark.

The lighting switches off immediately when the ignition is turned to the accessory position.

Activation or deactivation of this function can be changed in the menu **Vehicle Settings** in the Info-Display. Vehicle personalisation ⇨ 76.

Entrance lighting

The following lights will additionally illuminate when driver`s door is opened:

- All switches
- Driver Information Centre
- Some interior lights

Exit lighting

Headlights and tail lights illuminate the way for an adjustable time after leaving the vehicle.

Activation, deactivation and duration of lighting of this function can be changed in the menu **Vehicle Settings** in the Info-Display. Vehicle personalisation ⇨ 76.

Battery discharge protection

Switching off electric lights

To prevent discharge of the battery when the ignition is switched off, some interior lights are switched off automatically after some time.

Climate control

Climate control systems 84
Air vents 90
Maintenance 91

Climate control systems

Air conditioning system

(if fitted)

Controls for:

- Temperature
- Air distribution
- Fan speed
- Demisting and defrosting
- Air recirculation
- Cooling
- Heated rear window

⚠ Danger

Do not sleep in a vehicle with the air conditioning or heating system on. It may cause serious harm or death due to a drop in the oxygen level and/or body temperature.

Temperature

Adjust the temperature by turning the knob.

red = warm
blue = cold

Heating will not be fully effective until the engine has reached its operating temperature.

Air distribution

Select air outlet by pushing buttons.

- = to head area and footwell
- = to footwell
- = to head area via adjustable air vents
- = to windscreen and footwell

Fan speed

Adjust the air flow by switching the fan to the desired speed.

Air conditioning

Operated with the button and is functional only when the engine and fan are running.

The air conditioning system cools and dehumidifies (dries) the interior of the vehicle. Therefore condensation may form and drip from under the vehicle.

If cooling or drying is not required, switch the air conditioning system off to save fuel.

Note

When switching the air conditioning system on/off using the air conditioning button, the Info-Display will show **on** or **off**.

Air recirculation system

The air recirculation mode is operated with the button.

⚠Warning

Driving with recirculation mode for prolonged period of time can make you sleepy. Periodically turn to the outside air mode for fresh air.

The exchange of fresh air is reduced in air recirculation mode. In operation without cooling the air humidity increases, so the windows may mist up. The quality of the passenger compartment air deteriorates, which may cause the vehicle occupants to feel drowsy.

Demisting and defrosting the windows

Adjust the air flow by switching the fan to the desired speed.

- Push button : the air distribution is directed automatically to the windscreen.
- Set temperature control to warmest level.
- Switch on heated rear window .
- Open side air vents as required and direct them towards the door windows.

Note
When demist button is selected, the air conditioning is automatically switched on, but the air conditioning switch will not illuminate.

Heated rear window ⇨ 32.

Maximum cooling

Adjust the air flow by switching the fan to the desired speed.

Briefly open the windows so that hot air can disperse quickly.

- Switch on air conditioning .
- Switch on air recirculation system .
- Push air distribution switch .
- Set temperature control to coldest level.
- Set fan speed to highest level.
- Open all vents.

Indication of settings

(Info-Display)

Each change of settings is indicated in the Info-Display for a few seconds.

Selected functions are indicated by the LED of the activated button.

Note
The Info-Display will also show **on** or **off** when switching the air conditioning on/off via the air conditioning switch.

Electronic climate control system

(if fitted)

⚠Danger

Do not sleep in a vehicle with the air conditioning or heating system on. It may cause serious harm or death due to a drop in the oxygen level and/or body temperature.

Controls for automatic mode:

AUTO = automatic mode, all settings except temperature are choosen automatically by the system

Temperature = preselection of the desired temperature

The following functions can be adapted manually, disabling automatic mode:

Fan speed = selectable air flow

MODE = selectable air distribution

= demisting and defrosting

= switching system on or off

= switching cooling on or off

= air recirculation

AQS = air quality sensor

Heated rear window ⇨ 32.

The preselected temperature is automatically regulated. In the automatic mode the fan speed and air distribution automatically regulate the air flow.

The system can be manually adapted by use of air distribution and fan speed controls.

Each change of settings is indicated in the Info-Display for a few seconds.

Activated functions are indicated by the LED in the button.

The electronic climate control system is only fully operational when the engine is running.

Automatic mode AUTO

Basic setting for maximum comfort:

- Press **AUTO** button, the air conditioning is activated automatically.
- Open all air vents.
- Set pre-selected temperature using left rotary knob.

The fan speed regulation in automatic mode can be changed in the menu **Vehicle settings/Climate and air quality**.

Vehicle personalisation ⇨ 76

Air distribution is selected automatically in automatic mode. The air vents should therefore always be open.

Temperature preselection

Set temperature to the desired value by turning the knob.

red = warm
blue = cold

If the minimum temperature is set, the climate control system runs at maximum cooling.

If the maximum temperature is set, the climate control system runs at maximum heating.

Demisting and defrosting the windows

- Press button .
- Temperature and air distribution are set automatically and the fan runs to higher speed.
- To return to automatic mode: press button .

Switch on heated rear window .

Heated rear window ⇨ 32.

Manual settings

Climate control system settings can be changed by activating the buttons and rotary knobs as follows. Changing a setting will deactivate the automatic mode.

Fan speed

Turn right rotary knob. The selected fan speed is indicated by the number in the display.

To return to automatic mode: Press **AUTO** button.

Air distribution MODE

Press **MODE** button once or repeatedly for desired adjustment. The setting of air distribution is indicated on the Info-Display.

- = to windscreen, head area and foot well
- = to windscreen and foot well
- = to foot well
- = to head area via adjustable air vents
- = to head area via adjustable air vents and foot well

Return to automatic air distribution: Deactive corresponding setting or press button **AUTO**.

Cooling

Activate or deactivate with the button.

The air conditioning system cools and dehumidifies (dries) the interior of the vehicle. Therefore condensation may form and drip from under the vehicle.

If cooling or drying is not required, switch the air conditioning system off to save fuel.

Note

When switching the air conditioning system on/off using the air conditioning button, the Info-Display will show **on** or **off**.

Manual air recirculation mode

The manual air recirculation mode is operated with the button.

⚠Warning

The exchange of fresh air is reduced in air recirculation mode. In operation without cooling the air humidity increases, so the windows may mist up. The quality of the passenger compartment air deteriorates, which may cause the vehicle occupants to feel drowsy.

Air quality sensor AQS
(if fitted)

The air quality sensor detects poor quality ambient and switches automatically to internal air.

System switching on or off ⏻

Pushing button ⏻ switches all functions of heating, ventilation and cooling system on or off.

Basic settings

Some settings can be changed in the menu **Vehicle settings/Climate and air quality** in the Info-Display. Vehicle personalisation ⇨ 76.

Air vents

Adjustable air vents

At least one air vent must be open while cooling is on in order to prevent the evaporator from icing up due to lack of air movement.



To open vent, turn the adjuster wheel to ⁞⁞⁞.

Direct the flow of air by tilting and swivelling the slats.



To close the vent, turn the adjuster wheel fully to the left.

Fixed air vents

Additional air vents are located beneath the windscreen and door windows and in the footwells.

Maintenance

Air intake



The air intake in front of the windscreen in the engine compartment must be kept clear to allow air intake. Remove any leaves, dirt or snow.

Pollen filter

Manual controlled pollen filter

The filter cleans dust, soot, pollen, spore and smell (combi filter) from the air entering the vehicle through the air intake.

Air conditioning regular operation

In order to ensure continuously efficient performance, cooling must be operated for a few minutes once a month, irrespective of the weather and time of year. Operation with cooling may not be possible when outside temperature is low.

Service

For optimal cooling performance, it is recommended to have the climate control system checked annually by your Holden Dealer.

- Functionality and pressure test
- Heating functionality
- Leakage check

- Check of drive belts
- Cleaning of condenser and evaporator drainage
- Performance check

Driving and operating

Driving hints 93
Starting and operating 93
Engine exhaust 98
Automatic transmission 98
Manual transmission 102
Brakes 103
Ride control systems 104
Cruise control 106
Object detection systems 107
Fuel 110
Trailer hitch 112

Driving hints

Control of the vehicle

Never coast with engine not running

⚠ Danger

Many systems will not function in this situation (e.g. brake servo unit, power steering). Driving in this manner is a danger to yourself and others.

Pedals

To ensure the pedal travel is uninhibited, there must be no mats in the area of the pedals.

Starting and operating

New vehicle running-in

Use the following precautions for the first few hundred kilometres to improve the performance and economy of your vehicle and add to its long life:

- Avoid full-throttle starts.
- Do not race the engine.
- Avoid hard stops except in emergencies. This will allow your brakes to bed in properly.
- Avoid quick starts, sudden accelerations, and prolonged high-speed driving in order to avoid damage to the engine and to conserve fuel.
- Avoid full-throttle acceleration in low gear.
- Do not tow any other vehicle.

During the running-in period fuel and engine oil consumption may be higher.

Ignition switch positions



0 = Ignition off
1 = Ignition off, steering wheel lock released
2 = Ignition on
3 = Starting

Starting the engine

Starting engine with the ignition switch



- Turn the key to position **1**, move the steering wheel slightly to release the steering wheel lock
- Manual transmission: press and hold clutch pedal
- Automatic transmission: press and hold brake pedal and move shift lever to **P** or **N**
- Do not accelerate
- Turn the key to position **3** and release when engine is running

Before restarting or to switch off the engine, turn key back to **0**.

Starting engine with the Start/Stop button



- The electronic key must be inside the vehicle
- Manual transmission: depress clutch pedal
- Automatic transmission: depress brake and move shift lever to **P** or **N**

- Do not accelerate
- Press the Start/Stop button. The green LED will illuminate

To switch off the engine, press the button again.

Remote engine start (if fitted)

Vehicles with automatic transmission may have remote start. It allows the engine to be started from outside the vehicle.

ᑎ (Remote engine start): The remote start button is on the remote control ⇨ 19.

The climate control system will use the previous settings during a remote start. If the vehicle has heated seats, they may come on during a remote start. Heated front seats ⇨ 37.

Starting the vehicle

To start the engine using the remote start feature:

1. Aim the radio remote control at the vehicle.
2. Press and release ⍾.
3. Immediately after completing step 2, press and hold ᑎ for at least two seconds or until the turn signal lamps flash. The turn signal lamps flashing confirms the request to remote start the vehicle has been received.

When the engine starts, the parking lamps will turn on and remain on as long as the engine is running. The doors will be locked and the climate control system may come on.

The engine will continue to run for 10 minutes. Repeat the steps to extend to 20 minutes. Remote start can be extended only once.

If the engine is running when you enter the vehicle, press the brake pedal and press the engine Start/Stop button before moving the shift lever out of **P** (Park).

If the engine is not running when you enter the vehicle, start the engine ⇨ 94.

Extending engine run time

To extend to 20 minutes, repeat steps 1-3 while the engine is still running. The remote start can be extended once.

For example, if the engine has been running for five minutes, and the remote start is extended, the engine will run for a total of 20 minutes.

A maximum of two remote starts, or a single start with an extension, is allowed between ignition cycles.

The vehicle's ignition must be turned on and then back off before the remote start procedure can be used again.

Cancelling a remote start

To cancel a remote start, do one of the following:

- Aim the radio remote control at the vehicle and press and hold ☊ until the parking lamps turn off.
- Turn on the hazard warning flashers.
- Turn the vehicle on and then off.

Conditions in which remote start will not work

The remote vehicle start feature will not operate if:

- The key is in the ignition (key access) or if the key is in the vehicle (keyless access).
- The vehicle is unlocked.
- The bonnet is not closed.
- The hazard warning flashers are on.
- The malfunction indicator lamp is on.
- The engine coolant temperature is too high.
- The oil pressure is low.
- Two remote vehicle starts, or a single remote start with an extension, have already been used.
- The vehicle is not in **P** (Park).

Switching off the engine

- Push **Start/Stop** button while engine is running and vehicle stationary to switch off the engine.
- In case of emergency the engine can be switched off while the vehicle is running: push **Start/Stop** button twice.

⚠ Warning

When the engine is not running, considerably more force is needed to brake and steer.

Accessory power mode

Push **Start/Stop** button once without pressing clutch or brake pedal: **Accessory power mode** is active, the yellow LED in the button illuminates. In this mode steering wheel lock is released and some electrical functions are operable.

To start the engine from **Accessory power mode**, press clutch pedal (manual transmission) or brake pedal (automatic transmission) and push **Start/Stop** button once more.

Ignition on power mode

Push and hold **Start/Stop** button for 5 seconds without pressing clutch or brake pedal: **Ignition on power mode** is active, the green LED in the button illuminates. In this mode all electrical functions are operable.

To start the engine from **Ignition on power mode**, press clutch pedal (manual transmission) or brake pedal (automatic transmission) and push **Start/Stop** button once more.

Note

Do not put the electronic key in the boot or in front of the Info-Display.

Electronic key manual override

If either the battery of the electronic key is weak or the radio remote control fails, the driver's door can be locked or unlocked with the mechanical key ⇨ 19.

The mechanical key can only lock or unlock the driver's door. Unlocking the entire vehicle ⇨ 22. On vehicles with anti-theft alarm system, the alarm may be triggered when the vehicle is unlocked. Deactivate the alarm by switching on the ignition.

Locate the small circular cover in the bottom of the cupholder in the centre console. Place the electronic key over the cover with the Holden Logo facing up.

Press the **Start/Stop** button.

To switch off the engine, press the **Start/Stop** button for at least 2 seconds.

Lock the driver's door with the mechanical key. Locking the entire vehicle ⇨ 22.

This option is intended for manual override when the battery of the electronic key is weak, the radio remote control fails or there is interference from external higher power radio waves. If the issue persists seek the assistance of your Holden Dealer.

Overrun cut-off

The fuel supply is automatically cut off during overrun, i.e. when the vehicle is driven with a gear engaged but accelerator is released.

Parking

- Do not park the vehicle on an easily ignitable surface. The high temperature of the exhaust system could ignite the surface.
- Always apply parking brake without pressing release button. Apply as firmly as possible on downhill or uphill slopes. Depress the footbrake at the same time to reduce operating force.
- Switch off the engine and ignition. Turn the steering wheel until the steering wheel lock engages.
- If the vehicle is on a level surface or uphill slope, engage first gear or set the shift lever to **P** before switching off the ignition. On an uphill slope, turn the front wheels away from the kerb.

  If the vehicle is on a downhill slope, engage reverse gear or set the shift lever to **P** before switching off the ignition. Turn the front wheels towards the kerb.
- Lock the vehicle.

Engine exhaust

⚠ Danger

Engine exhaust gases contain poisonous carbon monoxide, which is colourless and odourless and could be fatal if inhaled.

If exhaust gases enter the interior of the vehicle, open the windows. Have the cause of the fault rectified by your Holden Dealer.

Avoid driving with an open boot lid, otherwise exhaust gases could enter the vehicle.

Catalytic converter

The catalytic converter reduces the amount of harmful substances in the exhaust gas.

Caution

Fuel specifications other than those listed on pages ⇨ 110, ⇨ 165 could damage the catalytic converter or electronic components.

Unburnt petrol will overheat and damage the catalytic converter. Therefore avoid excessive use of the starter, running the fuel tank dry and starting the engine by pushing or towing.

In the event of misfiring, uneven engine running, a reduction in engine performance or other unusual problems, have the cause of the fault rectified by your Holden Dealer as soon as possible. In an emergency, driving can be continued for a short period, keeping vehicle speed and engine speed low.

Automatic transmission

The automatic transmission permits manual gear-shifting (manual mode) or automatic gear-shifting (automatic mode).

Transmission display

The mode or selected gear is shown in the transmission display.

Different displays are used depending on model.

Shift lever

P = park position, wheels are locked, engage only when the vehicle is stationary and the parking brake is applied
R = reverse gear, engage only when vehicle is stationary
N = neutral
D = automatic mode with all gears.

The shift lever is locked in **P**. To move, switch on ignition, apply brake pedal and push release button.

To engage **P** or **R**, push the release button.

To start the engine, press the brake pedal in either **P** or **N** position.

Do not accelerate while engaging a gear. Never depress the accelerator pedal and brake pedal at the same time.

When a gear is engaged, the vehicle slowly begins to creep when the brake is released.

Engine braking

To utilise the engine braking effect, select a lower gear in good time when driving downhill.

Refer to manual mode ⇨ 100

Rocking the vehicle

Rocking the vehicle is only permissible if the vehicle is stuck in sand, mud or snow. Move the shift lever between **D** and **R** in a repeat pattern. Do not race the engine and avoid sudden acceleration.

Parking

Apply the parking brake, engage **P** and remove ignition key.

Sport mode

(If fitted)



The sport mode can be selected where maximum responsiveness is required.

When operated in sport mode, the transmission will delay upshifts and allow earlier downshifts.

In addition, the transmission can sense enthusiastic driving, at which point it may delay upshifting and downshift earlier when braking. This is designed to maximise vehicle performance.

To activate sport mode:

1. Move shift lever to position **D**.
2. Push the shift lever to the left.

   Sport Mode On will appear for 3 seconds in the Driver Information Centre.

   Do not move the shift lever to **+** or **-**, otherwise the manual mode will be enabled.
3. To return to normal mode, move the shift lever to the right, to position **D**.

   Sport Mode Off will appear for 3 seconds in the Driver Information Centre.

Manual mode



Move shift lever out of position **D** towards the left and then forwards or backwards.

+ = Shift to a higher gear.

– = Shift to a lower gear.

If a higher gear is selected when vehicle speed is too low, or a lower gear when vehicle speed is too high, the shift is not executed.

If engine speed is too low, the transmission automatically shifts to a lower gear above a specific vehicle speed.

No automatic shifting to a higher gear takes place at high engine revolutions.

For reasons of safety, kickdown is also available in manual mode.

Electronic driving programmes

- Following a cold start, the operating temperature programme increases engine speed to quickly bring the catalytic converter to the required temperature.
- The automatic neutral shift function automatically shifts to idling when the vehicle is stopped with a forward gear engaged.

Kickdown



If the accelerator pedal is pressed past the pressure point, the transmission shifts to a lower gear depending on engine speed.

Fault

In the event of a fault, illuminates. Additionally a code number is displayed in the Driver Information Centre. Vehicle messages ⇨ 73.

The transmission no longer shifts automatically. Continued travel is possible with manual shifting.

Only the highest gear is available. Depending on the fault, 2nd gear may also be available in manual mode.

Have the cause of the fault remedied by your Holden Dealer.

Interruption of power supply

In the event of an interruption of power supply, the shift lever cannot be moved out of the **P** position. The ignition key cannot be moved out of the ignition lock.

If the battery is discharged, start the vehicle using jump leads ⇨ 152.

If the battery is not the cause of the fault, release shift lever and remove ignition key from ignition lock.

Release shift lever

1. Apply parking brake.

2. Open cover to the right of the shift lever.

3. Insert a screwdriver into the opening as far as it will go and move the shift lever out of **P**. If **P** is engaged again, the shift lever will be locked in position again. Have the cause of the power supply interruption remedied by your Holden Dealer.
4. Close cover.

Manual transmission



Reverse: when the vehicle is stationary, depress the clutch pedal and then pull up the ring on the shift lever and engage the gear.

If the gear does not engage, set the lever in neutral, release the clutch pedal and depress again; then repeat gear selection.

Do not grind the clutch unnecessarily.

When operating, depress the clutch pedal completely. Do not use the pedal as a foot rest.

Caution
It is not advisable to drive with your hand resting on the shift lever.

Brakes

The brake system comprises two independent brake circuits.

If a brake circuit fails, the vehicle can still be braked using the other brake circuit. However, braking effect is achieved only when the brake pedal is depressed firmly. Considerably more force is needed for this. The braking distance is extended. Seek the assistance of your Holden Dealer before continuing your journey.

When the engine is not running, the support of the brake servo unit disappears once the brake pedal has been depressed once or twice. Braking effect is not reduced, but braking requires significantly greater force. It is especially important to bear this in mind when being towed.

Control indicator ⓘ ⇨ 68.

Antilock brake system

Antilock brake system (ABS) prevents the wheels from locking.

ABS starts to regulate brake pressure as soon as a wheel shows a tendency to lock. The vehicle remains steerable, even during hard braking.

ABS control is made apparent through a pulse in the brake pedal and the noise of the regulation process.

For optimum braking, keep the brake pedal fully depressed throughout the braking process, despite the fact that the pedal is pulsating. Do not reduce the pressure on the pedal.

If the vehicle is travelling above 50 km/h and ABS braking occurs, the centrally mounted rear high level stop lamp will flash.

Control indicator (ABS) ⇨ 68.

Fault

⚠ Warning

If there is a fault in the ABS, the wheels may be liable to lock due to braking that is heavier than normal. The advantages of ABS are no longer available. During hard braking, the vehicle can no longer be steered and may swerve.

Have the cause of the fault remedied by your Holden Dealer.

Parking brake



Always apply parking brake firmly without operating the release button, and apply as firmly as possible on a downhill or uphill slope.

When applying the parking brake, depress the foot brake firmly at the same time.

To release the parking brake, pull the lever up slightly, press the release button and fully lower the lever.

Control indicator ⓘ BRAKE ⇨ 68.

Brake assist

If the brake pedal is depressed quickly and forcefully, maximum brake force is automatically applied (full braking).

Maintain steady pressure on the brake pedal for as long as full braking is required. Maximum brake force is automatically reduced when the brake pedal is released.

Ride control systems

Traction control system

Traction control system (TC) improves driving stability when necessary, regardless of the type of road surface or tyre grip, by preventing the driving wheels from spinning.

As soon as the driving wheels start to spin, engine output is reduced and the wheels are braked individually. This considerably improves the driving stability of the vehicle on slippery road surfaces.

TC is operational as soon as the control indicator 🚘 extinguishes after engine start up.

When TC is active 🚘 flashes.

⚠Warning

Do not let this special safety feature tempt you into taking risks when driving.

Adapt speed to the road conditions.

Control indicator 🚘 ⇨ 69.

Deactivation

TC can be switched off when spinning of drive wheels is required: press button 🚘.

Control indicator 🚘 illuminates.

TC is reactivated by pressing the button again.

TC is also reactivated the next time the ignition is switched on.

Note
On manual transmission vehicles, the button is located on the right side of the console.

Electronic stability control

Electronic stability control (ESC) improves driving stability when necessary, regardless of the type of road surface or tyre grip. It also prevents the driving wheels from spinning.

As soon as the vehicle starts to swerve (understeer/oversteer), engine output is reduced and the wheels are braked individually. This considerably improves the driving stability of the vehicle on slippery road surfaces.

ESC is operational as soon as the control indicator extinguishes after engine start up.

When ESC is active flashes.

⚠ Warning

Do not let this special safety feature tempt you into taking risks when driving.

Adapt speed to the road conditions.

Control indicator ⇨ 69.

Deactivation

For very high-performance driving ESC can be deactivated: hold button depressed for approx. 7 seconds.

Control indicator illuminates and both ESC and TC are deactivated.

ESC is reactivated by pressing the button again. If the TC System was previously disabled, both TC and ESC are reactivated.

ESC is also reactivated the next time the ignition is switched on.

Note
On manual transmission vehicles, the button is located on the right side of the console.

Cruise control

The cruise control can store and maintain speeds. Deviations from the stored speeds may occur when driving uphill or downhill.

For safety reasons the cruise control cannot be activated until the foot brake has been operated once after engine start up.

With automatic transmission, only activate cruise control in automatic mode.

Control indicator ⏲ ⇨ 70.

Switching on

Press rocker switch ⏲ at the upper end, control indicator ⏲ illuminates white.

Activation

Accelerate to the desired speed and turn thumb wheel to **SET/-**, the current speed is stored and maintained. Control indicator ⏲ illuminates green. Accelerator pedal can be released.

Vehicle speed can be increased by depressing the accelerator pedal. When the accelerator pedal is released, the previously stored speed is resumed.

Increase speed

With cruise control active, hold thumb wheel turned to **RES/+** or briefly turn to **RES/+** repeatedly: speed increases continuously or in small increments.

Alternatively accelerate to the desired speed and store by turning to **RES/+**.

Reduce speed

With cruise control active, hold thumb wheel turned to **SET/-** or briefly turn to **SET/-** repeatedly: speed decreases continuously or in small increments.

Deactivation

Press button ⏲, control indicator ⏲ illuminates white. Cruise control is deactivated. The stored speed is maintained.

Automatic deactivation:

- vehicle speed below approx. 30 km/h,
- the brake pedal is depressed,
- the clutch pedal is depressed,
- shift lever in **N**,
- the Traction Control system or Electronic Stability Control is operating.

Resume stored speed

Turn thumb wheel to **RES/+** at a speed above 40 km/h. The stored speed will be obtained.

Switching off

Press rocker switch ⏲ at the lower end, control indicator ⏲ is off. The stored speed is deleted. Switching off the ignition deletes also the stored speed.

Object detection systems

Parking assist

(If fitted)



The parking assist makes parking easier by measuring the distance between the vehicle and rear obstacles, and giving acoustic signals. It is the driver, however, who bears full responsibility for parking manoeuvre.

The system consists of four ultrasonic parking sensors in the rear bumper.

Control indicator P⁄▲ ⇨ 69.

Note

Attached parts in the detection area cause system malfunction.

Activation

When reverse gear is engaged, the system is activated automatically.

An obstacle is indicated by acoustic warnings. The interval between the warnings becomes shorter as the vehicle gets closer to the obstacle. When the distance is less than 40 cm, the acoustic warning sounds continuously.

Deactivation

The system is deactivated automatically when:

- the vehicle is driven above 10 km/h
- the vehicle is parked
- a fault in the system occurs.

Fault

In the event of a fault in the system, P⁄▲ illuminates.

Additionally if the system does not work due to temporary conditions like snow covered sensors, P illuminates.

Important hints for using the parking assist systems

⚠Warning

Under certain circumstances, various reflective surfaces on objects or clothing as well as external noise sources may cause the system to fail to detect obstacles.

Caution

Sensor performance may be reduced when sensors are covered, e.g. by ice or snow.

Performance of the parking assist system may be reduced due to heavy loading.

Special conditions apply if there are taller vehicles involved (e.g. off-road vehicles, mini vans, vans). Object identification in the upper part of these vehicles cannot be guaranteed.

Objects with a very small reflection cross section, such as objects of narrow size or soft materials, may not be detected by the system.

Parking assist will not avoid a collision with objects which are outside the detection range of the sensors.

Note

Sensor could detect a nonexisting object (echo disturbance) caused by external acoustical or mechanic disturbances.

Rear view camera

(if fitted)

The rear view camera assists the driver when reversing by displaying a view of the area behind the vehicle.

The view of the camera is displayed in the Colour-Info-Display.

⚠Warning

The rear view camera does not replace driver vision. Note that objects that are outside the camera's field of view and the advanced parking assist sensors, e.g. below the bumper or underneath the vehicle, are not displayed.

Do not reverse the vehicle by only looking at the Info-Display. Check the surroundings behind and around the vehicle before reversing.

Activation

Rear view camera is automatically activated when reverse gear is engaged.

Functionality



4 Door sedan: The camera is mounted under the boot lid moulding.



5 Door hatchback: The camera is mounted in the rear bumper above the license plate.



Sportwagon: The camera is mounted under the boot lid moulding.

The camera has a viewing angle of 130°. Due to the positioning of the camera the rear bumper can be seen on the display as a guide to position.

The area displayed by the camera is limited. The distance of the image that appears on the display differs from the actual distance.

Warning symbols and guide lines
Warning symbols are indicated as triangles ⚠on the picture which show obstacles detected by the rear sensors of the advanced parking assist.



Guide lines assist with reversing by moving, to show the vehicle's intended path.

These functions can be deactivated in the menu **Vehicle Settings** in the Info-Display. Vehicle personalisation ⇨ 76.

Display settings
Brightness can be set with the instrument panel illumination control ⇨ 82.

Deactivation

The camera is deactivated when a certain forward speed is exceeded or if reverse gear is not engaged for approx. 10 seconds.

Activation or deactivation of the rear view camera can be changed in the menu **Vehicle Settings** in the Info-Display. Vehicle personalisation ⇨ 76.

Fault

The rear view camera may not operate properly when:

- the surrounding is dark,
- the sun or the beam of headlights is shining directly into the camera lens,
- ice, snow, mud, or anything else covers the camera lens. Clean the lens, rinse it with water, and wipe it with a soft cloth,
- the boot lid is not closed correctly (4 Door sedan),
- the vehicle had a rear end accident,
- there are extreme temperature changes.

Fuel

Fuel for petrol engines

Use clean, unleaded petrol of regular 91 Research Octane Number (RON) rating or higher.

Use of Premium unleaded petrol (95 RON or higher) on the 1.8L engine may provide a small improvement in performance and fuel economy.

Use of Premium unleaded petrol (95 RON or higher) on the 1.6L engine is recommended.

Purchasing your fuel from a reputable fuel retailer may reduce the risk of purchasing fuel which contains abnormal fuel properties.

Caution
Use of fuel with too low an octane rating could lead to uncontrolled combustion and engine damage.

Equivalent standardised fuels with an ethanol content of max. 10% by volume may be used.

⚠Warning

Under no circumstances should you use fuel containing more than 10% ethanol. Use of such fuels may result in engine malfunction, starting and operating difficulties, and materials degradation. These adverse effects could result in permanent damage to your vehicle and the risk of personal injury. Purchasing your fuel from a reputable fuel retailer may reduce the risk of purchasing fuel with more than 10% ethanol or fuel which contains abnormal fuel properties.

Refuelling

⚠Danger

Before refuelling, switch off engine and mobile phones.

Follow the operating and safety instructions of the filling station when refuelling.

⚠Danger

Fuel is flammable and explosive. No smoking. No naked flames or sparks.

If you can smell fuel in your vehicle, have the cause of this remedied immediately by your Holden Dealer.

Fuel filler flap is located at right rear side of vehicle.

The fuel filler flap can only be opened if the vehicle is unlocked. Release the fuel filler flap by pushing the flap.

To open, turn the cap slowly anti-clockwise.



The fuel filler cap can be retained in the bracket on the fuel filler flap.

When refuelling, fully insert the pump nozzle.

Caution
Wipe off any overflowing fuel immediately.

To close, turn the fuel filler cap clockwise until it clicks.

Close the flap and latch.

Fuel filler cap

Only a genuine fuel filler cap provides full functionality.

Trailer hitch

General information

The word 'Trailer' is used throughout this section and is intended to include all types of towed vehicles, such as a caravan, boat trailer or any other special purpose trailer.

The vehicle is designed primarily as a passenger vehicle, so handling, durability and economy may be affected by towing a trailer. Your Holden Dealer will help supply and install towing equipment to suit your requirements.

Trailer towing ⇨ 113.

Trailer towing

Overloading

Never exceed the loads given for the towing equipment fitted to the vehicle. For your safety and the vehicle's durability, all mandatory equipment must be fitted. Otherwise you may void the New Vehicle Warranty, to the extent that Holden considers the overloading or missing equipment to have affected the specifications or quality of the vehicle.

Maximum towing capacities (kg)

Engine	Transmission	Type	Caravan/ Trailer
Petrol (1.6L), Petrol (1.8L)	Manual transmission	With brake	1200
		Without brake	750
	Automatic transmission	With brake	1200
		Without brake	750

Mandatory equipment: Holden 1,200 kg rated towbar and Holden trailer wiring harness.

⚠Warning

Holden towing equipment is recommended where it is available. Where it is not available, no recommendation is made as to the make of equipment to be used. Holden will not accept liability for defects occurring in inappropriate towing equipment, for defects in the vehicle arising from the use of such equipment or for loss or injury caused by use of such equipment.

The use of inappropriate equipment may void your New Vehicle Warranty to the extent that Holden considers the overloading or missing equipment to have affected the specifications or quality of your vehicle.

Towing with Electronic Stability Control (ESC)

You may hear noise from the ESC modulator when it is working. The ESC is reacting to the vehicle movement caused by the trailer, which mainly occurs during cornering. This is considered normal when towing heavier trailers.

Recommended procedure for attaching a trailer



When a trailer is hitched to the vehicle, it places a weight on the tow bar. This weight is called the 'tow ball load'.

If the tow ball load is too light or too heavy, the steering and handling of the vehicle may be affected.

As a general guideline, for single axle trailers, the ball load should be approximately 10 % of the loaded trailer mass. For heavy trailers with more than one axle, the ball load should be in the range of 5 % - 10 % of the loaded trailer mass.

Note
The tow ball load should not exceed 75 kg.

The tow ball load can be adjusted by correctly packing the contents of the trailer. For example, by moving items forwards or backwards within the trailer so as to change the balance of the trailer.

Check the tow ball load before coupling the trailer to the towing vehicle.



If the attitude of the vehicle is compromised, adjust the vehicle and trailer load within the specifications to improve the attitude. If the vehicles attitude cannot be corrected, use a load distribution hitch.

Note

At no time may the maximum towing capacity exceed the maximums specified. Refer to Maximum towing capacity previously in this chapter.

At no time may the total rear axle load exceed the maximums specified. Refer to Loading the vehicle previously in this chapter.

Towing precautions

- When heavily loading your vehicle or when towing, your tyres should be inflated to the maximum recommended pressure. Refer to tyre pressure placard and information about tyre pressures ⇨ 141.
- Tighten the tow ball retaining nut to 140 Nm (Newton Meters) and check the torque frequently.
- Vehicles handle differently when towing. It is a good idea to make a couple of short distance trips with the trailer before setting off on a longer journey.
- Have your vehicle correctly maintained and serviced.

- Have the trailer maintained and serviced, with particular attention to the condition of the brakes, tyres, suspension, wheel bearings, lighting and the tow coupling.
- Use extended-arm rear view mirrors on both sides of the vehicle if necessary.
- Headlamps may need realignment after the loaded trailer has been hitched.
- Use a lower gear and the brakes, when descending steep hills.
- Do not use axle-mounted hitches as this will damage the vehicle.
- Ensure that no part of the tow bar (including the tongue or tow ball) obscures the vehicle's licence plate. If necessary, remove the tow bar tongue when it is not in use.
- If a tow bar is removed: Ensure to have any mounting holes in the underbody properly sealed to prevent the possible entry of exhaust fumes, dust and water.

Trailer brakes

- Trailer brakes are mandatory on trailers weighing 750 kg and over when loaded. The brakes on the trailer must be designed to cope with the braking requirements of the trailer under all towing conditions, without adversely affecting the brakes on the vehicle.
- Contact the appropriate regulatory body in your State or Territory for the legal requirements of trailer brakes.

Fitting accessories (bull bars, driving lamps, insect screens, etc)

When fitting accessories, take care not to restrict airflow through the air conditioner condenser and the radiator, otherwise engine overheating and/or poor air conditioning performance may result.

The mass of all accessories must be considered when evaluating the vehicle's overall loaded condition.

Remember that bull bars may affect airbag operation.

Running in before towing

Holden recommends that you drive your new vehicle for at least 1,500 km before towing. If you must tow in the first 1,500 km of the vehicle's life, do not exceed 80 km/h.

The same applies if the vehicle is equipped with a new or reconditioned engine, transmission or axle.

Vehicle maintenance

More frequent vehicle maintenance is required when using the vehicle for towing. Refer to the Service/warranty booklet in the vehicle's glovebox.

Vehicle care

General information 118
Vehicle checks 119
Bulb replacement 127
Electrical system 136
Vehicle tools 140
Wheels and tyres 141
Jump starting 152
Towing 154
Appearance care 155

General information

Accessories and vehicle modifications

We recommend to use Genuine Parts and Accessories and factory approved parts specific for your vehicle type. We cannot assess or guarantee the suitability or performance of other products, even if they have regulatory or other approval.

Do not make any modifications to the electrical system, e.g. changes of electronic control units (chip tuning).

Vehicle storage

Storage for a long period of time

If the vehicle is to be stored for several months:

- Wash and wax the vehicle.
- Clean and preserve rubber seals.
- Fill up fuel tank completely.
- Change engine oil.
- Drain washer fluid reservoir.
- Check coolant anti-freeze and corrosion protection.
- Adjust tyre pressure to the value specified for full load.
- Park vehicle in dry, well ventilated place. Engage first or reverse gear or set shift lever to **P**. Prevent the vehicle from rolling.
- Do not apply parking brake.
- Open bonnet, close all doors and lock the vehicle.
- Disconnect the clamp from the negative terminal of the vehicle battery. Beware that all systems are not functional, e.g. anti-theft alarm system.

Putting back into operation

When the vehicle is to be put back into operation:

- Connect the clamp to the negative terminal of the vehicle battery. Activate the electronic of the power windows.
- Check tyre pressure.
- Fill up the washer fluid reservoir.

- Check the engine oil level.
- Check the coolant level.

Vehicle checks

Performing work



⚠Warning

Only perform engine compartment checks when the ignition is off.

The cooling fan may start operating even if the ignition is off.

⚠Danger

The ignition system uses extremely high voltage. Do not touch.

Bonnet

Opening



Pull the release lever and return it to its original position.

Push the safety catch to the right and open the bonnet.



Secure the bonnet support.

Closing

Before closing the bonnet, press the support into the holder.

Lower the bonnet and allow it to drop into the catch. Check that the bonnet is engaged.

Engine compartment overview

1.6L Petrol engine



1.8L Petrol engine



1. Power steering fluid container ⇨ 125
2. Brake fluid container ⇨ 126
3. Engine oil cap ⇨ 123
4. Engine coolant container ⇨ 124
5. Fuse box ⇨ 137
6. Washer fluid container ⇨ 126
7. Battery ⇨ 126
8. Dipstick for engine oil level ⇨ 123
9. Engine air filter ⇨ 124

Engine oil

It is advisable to check the engine oil level manually before embarking on a long journey.

Check with the vehicle on a level surface. The engine must be at operating temperature and switched off for at least 10 minutes.

Pull out the dipstick, wipe it clean, insert it to the stop on the handle, pull out and read the engine oil level.

Insert dipstick to the stop on the handle and make half a turn.

Different dipsticks are used depending on engine variant.

1.6L Petrol:



1.8L Petrol (4 Door sedan, 5 Door hatchback):



1.8L Petrol (Sportwagon):



When the engine oil level has dropped to the **MIN** mark, top up engine oil.



Refer to the manufacturers specifications on engine oil ⇨ 158.

The engine oil level must not exceed the **MAX** mark on the dipstick.

Caution
Overfilled engine oil must be drained or suctioned out.

Replace oil cap and tighten it.

Caution
When driving at a slope, the warning code 79 might be displayed in the Driver Information Centre ⇨ 73. If the code disappears when driving in a flat area again, do not top up engine oil.

Engine air filter



To replace engine air filter unscrew 6 screws and remove air filter housing.

Engine coolant

The coolant provides freeze protection down to approx. -28 °C.

⚠Warning
Do not spill coolant on the vehicle's exterior surfaces. It can damage the paintwork. If you do, wash it off immediately.

Caution
Only use approved anti-freeze.

Coolant level

Caution
Too low a coolant level can cause engine damage.



If the cooling system is cold, the coolant level should be above the filling line mark. Top up if the level is low.

⚠Warning

Allow the engine to cool before opening the cap. Carefully open the cap, relieving the pressure slowly.

Top up with antifreeze. If no antifreeze is available, use clean tap water or distilled water. Install the cap tightly. Have the antifreeze concentration checked and have the cause of the coolant loss remedied by your Holden Dealer.

Power steering fluid

Caution

Extremely small amounts of contamination can cause steering system damage and cause it to not work properly. Do not allow contaminates to come into contact with the fluid side of the reservoir cap/dipstick or to enter the reservoir.



Open the cap and remove. Wipe the dipstick dry and turn the cap in the reservoir. Open the cap again and read the power steering fluid level.

The power steering fluid level must be between the **MIN** and the **MAX** marks.

If the fluid level is too low, seek the assistance of your Holden Dealer.

Washer fluid

Fill with clean water mixed with a suitable quantity of windscreen wash solution.

Brake fluid

⚠Warning

Brake fluid is poisonous and corrosive. Avoid contact with eyes, skin, fabrics and painted surfaces.



The brake fluid level must be between the **MIN** and the **MAX** marks.

When topping up, ensure maximum cleanliness as contamination of the brake fluid can lead to brake system malfunctions. Have the cause of the loss of brake fluid remedied by your Holden Dealer.

Only use high-performance brake fluid approved for the vehicle. Brake and clutch fluid ⇨ 158.

Vehicle battery

The vehicle is equipped with a lead acid battery. The battery is maintenance-free.

Caution

A specifically developed battery with a ventilation system is required for this vehicle. Only use a manufacturer recommended battery as a replacement.

Non use of the vehicle for more than 4 weeks can lead to battery discharge. Disconnect the clamp from the negative terminal of the vehicle battery.

Ensure the ignition is switched off before connecting or disconnecting the vehicle battery.

Battery discharge protection ⇨ 83.

Wiper blade replacement



Lift wiper arm. Move release lever and detach wiper blade.

Wiper blade on the rear window (Hatch & Sportwagon)

Lift wiper arm. Disengage wiper blade as shown in illustration and remove.

Attach the wiper blade slightly angled to the wiper arm and push until it engages.

Lower wiper arm carefully.

Bulb replacement

Switch off the ignition and switch off the relevant switch or close the doors.

Only hold a new bulb at the base! Do not touch the bulb glass with bare hands.

Use only the same bulb type for replacement.

Replace headlight bulbs from within the engine compartment.

Halogen headlights

Low beam and high beam

1. Detach plug connector from bulb.



2. Remove protective cover.



3. Press spring clip, disengage and swivel it upward.
4. Remove bulb from reflector housing.
5. When fitting a new bulb, engage the lugs in the recesses on the reflector.
6. Engage the spring clip.
7. Place headlamp protective cover in position.
8. Plug connector onto bulb.

Parking lights

1. Detach plug connector from bulb.



2. Remove protective cover.



3. Remove side light bulb holder from reflector.



4. Remove bulb from socket.
5. Insert new bulb.

6. Insert holder in reflector.
7. Place headlamp protective cover in position.
8. Plug connector onto bulb.

Front turn signal lights



1. Rotate bulb holder anti-clockwise and disengage.



2. Push bulb into socket slightly, rotate anti-clockwise, remove and renew bulb.
3. Insert bulb holder in reflector, rotate clockwise to engage.

Fog lights

Have bulbs replaced by your Holden Dealer.

Daytime Running Lights (LED)

Have the lamps replaced by your Holden Dealer.

Tail lights

4 Door sedan



1. Open both covers.

2. Unscrew both screws.



3. Remove tail light assembly. Take care that the cable duct remains in position.



4. Reverse light (**1**)
   Turn signal light (**2**)
   Tail light/brake light (**3**)



5. Rotate bulb holder anti-clockwise.



6. Remove bulb holder. Push bulb into socket slightly, rotate anti-clockwise, remove and renew bulb.
7. Insert bulb holder into the tail light assembly and rotate clockwise into place. Install tail light assembly in body and tighten screws. Close covers and engage.
8. Switch on ignition, operate and check all lights.

Tail lights in boot lid

1. Remove the boot lid panelling.
2. Rotate bulb holder anti-clockwise.



3. Remove bulb holder. Push bulb into socket slightly, rotate anti-clockwise, remove and renew bulb.
4. Insert bulb holder into boot. Refit the inner panelling to boot lid.
5. Switch on ignition, operate and check the lights.

5 Door hatchback



1. Open the three covers.



2. Unscrew the three screws.



3. Remove tail light assembly. Take care that the cable duct remains in position.



4. Turn signal light (**1**)
   Tail light/brake light (**2**)



5. Rotate bulb holder anti-clockwise.



6. Remove bulb holder. Push bulb into socket slightly, rotate anti-clockwise, remove and renew bulb.
7. Insert bulb holder into the tail light assembly and screw into place. Connect wiring plug. Install tail light assembly in body and tighten screws. Close covers and engage.
8. Switch on ignition, operate and check all lights.

Reverse light

Have bulb replaced by a workshop.

Sportwagon

1. Open both covers.



2. Unscrew both screws.



3. Remove tail light assembly. Take care that the cable duct remains in position.



4. Turn signal light (**1**)
   Tail light/brake light (**2**)



5. Rotate bulb holder anti-clockwise.



6. Remove bulb holder. Push bulb into socket slightly, rotate anti-clockwise, remove and renew bulb.
7. Insert bulb holder into the tail light assembly and screw into place. Install tail light assembly in body and tighten screws. Close covers and engage.
8. Switch on ignition, operate and check all lights.

Tail lights in boot lid

1. Open the tailgate and remove the cover on the respective side.



2. Remove the bulb holder by turning anti-clockwise. Replace the bulb by pulling out of the socket, and then pushing in the replacement bulb.

   Reverse light (**1**).

   Tail light (**2**).
3. Insert bulb holder and turn clockwise. Attach cover.
4. Switch on ignition, operate and check the lights.

Side turn signal lights

Have bulbs replaced by your Holden Dealer.

Number plate light

4 Door sedan



1. Unscrew both screws.



2. Remove bulb housing downward, taking care not to pull on the cable.

   Rotate bulb holder anti-clockwise to disengage.
3. Remove bulb from holder and renew bulb.
4. Insert bulb holder in bulb housing and rotate clockwise.
5. Insert bulb housing and secure using a screwdriver.

5 Door hatchback, Sportwagon

1. Insert screwdriver in bulb housing, press to the side and release spring.
2. Remove bulb housing downward, taking care not to pull on the cable.

3. Rotate bulb holder anti-clockwise to disengage.
4. Remove bulb from holder and renew bulb.
5. Insert bulb holder in bulb housing and rotate clockwise.
6. Insert and engage bulb housing.

Interior lights

Courtesy light, reading lights

Have bulbs replaced by your Holden Dealer.

Load compartment light



1. Prise the lamp out with a screwdriver.



2. Press bulb slightly towards spring clip and remove.
3. Insert new bulb.
4. Install lamp.

Instrument panel illumination

Have bulbs replaced by your Holden Dealer.

Electrical system

Fuses

Data on the replacement fuse must match the data on the defective fuse.

There are two fuse boxes in the vehicle:

- in the front left of the engine compartment,
- in the interior behind the glovebox.

In a box above the positive terminal of the battery are some main fuses. If necessary have them changed by your Holden Dealer.

Before replacing a fuse, turn off the respective switch and the ignition.

A blown fuse can be recognised by its melted wire. Do not replace the fuse until the cause of the fault has been remedied.

Some circuits are protected by several fuses.

Fuses may also be inserted into a blank cavity, where there is no circuit.



30040

30041

Fuse extractor

A fuse extractor may be located in the fuse box in the engine compartment.



30042



30042



30044

Place the fuse extractor on the various types of fuse from the top or side, and withdraw fuse.

Engine compartment fuse box



The fuse box is in the front left of the engine compartment.

Disengage the cover, lift it upwards and remove.

No.	Circuit
1	Transmission control module
2	Engine control module
3	–
4	Canister vent sol
5	Ignition
6	Front wipers
7	–
8	Fuel injector 2, 4
9	Fuel injector 1, 3
10	Engine control module
11	Lambda sensor
12	Starter solenoid
13	Canister vent sol
14	–
15	Rear wiper
16	Ignition, Air quality sensor
17	Ignition, Airbag

No.	Circuit
18	Fuel system control module
19	–
20	Fuel pump
21	Rear power windows
22	–
23	–
24	Front power windows
25	Electronic vacuum pump
26	ABS
27	Electronic key system
28	Heated rear window
29	–
30	ABS
31	Body control module
32	Body control module
33	Front seat heating
34	–

No.	Circuit
35	Infotainment system, Amplifier
36	–
37	High beam, right side
38	High beam, left side
39	–
40	–
41	–
42	Cooling fan
43	–
44	–
45	Cooling fan
46	Cooling fan
47	Lambda sensor
48	Fog lights
49	–
50	–
51	Horn

No.	Circuit
52	Instrument panel
53	Electrochromatic mirror
54	Light switch, Light control
55	Mirror folding
56	Windscreen washer
57	Steering column lock
58	–
59	–
60	Mirror heating
61	Mirror heating
62	Air conditioning
63	Rear window sensor
64	Air quality sensor
65	Rear fog lamp
66	Rear washer
67	Fuel system control module
68	–
69	Battery voltage sensor
70	Rain sensor
71	–

Instrument panel fuse box

The fuse box is located behind a cover in the glovebox. Open the glovebox and remove the cover.



No.	Circuit
1	Infotainment system, handsfree phone
2	-
3	Body control module
4	Infotainment system
5	Display/faceplate, parking assist, power sounder
6	Cigarette lighter
7	Power outlet

No.	Circuit
8	Body control module
9	Body control module
10	Body control module
11	Interior fan
12	-
13	Heated seats
14	Diagnostic connector
15	Airbag
16	Central locking system
17	Air conditioning system
18	Trailer wiring power
19	Shift lever
20	-
21	Instruments
22	Ignition, Electronic key system
23	Body control module
24	Body control module
25	Steering column lock
26	Rear power outlet

Vehicle tools

Tools

Vehicles with tyre repair kit



The tools and tyre repair kit are in a storage compartment below the floor cover in the boot.

Vehicles with spare wheel

The jack and the tools are in a stowage compartment in the boot below the spare wheel. Spare wheel ⇨ 150.



A LONG wheel tub stud may also be stored with the vehicle tools.

Wheels and tyres

Tyre condition, wheel condition

Drive over edges slowly and at right angles if possible. Driving over sharp edges can cause tyre and wheel damage. Do not trap tyres on the kerb when parking.

Regularly check the wheels and tyres for damage. Seek the assistance from your Holden Dealer in the event of damage or unusual tyre wear.

Tyre pressure

Check the pressure of cold tyres at least every 14 days and before any long journey. Do not forget the spare wheel.

Unscrew the valve cap.



Refer to the tyre pressure placard on the front right door frame.

The tyre pressure data refers to cold tyres.

Always inflate the spare tyre to the pressure specified for full load.

Incorrect tyre pressures will impair safety, vehicle handling, comfort and fuel economy and will increase tyre wear.

⚠Warning

If the pressure is too low, this can result in considerable tyre warm-up and internal damage, leading to tread separation and even to tyre blow-out at high speeds.

Tread depth

Check tread depth at regular intervals.

Tyres should be replaced for safety reasons when

1. The tyres are worn to the point where the tread indicators as shown, appear or the cord or fabric is showing.
2. The tread or side wall is cut, split, or cracked deep enough to expose the cord or fabric.
3. The tyre has a bump or bulge in it, indicating some kind of internal damage.
4. The tyre has a puncture, cut or other damage which cannot be repaired because of the size or location of the damage. If in doubt about the extent of the damage to the tyre, have it removed from the wheel and examined by a tyre specialist.

The legally permissible minimum tread depth (1.6 mm) has been reached when the tread has worn down as far as one of the tread wear indicators (TWI). Their position is indicated by markings on the sidewall.

If there is more wear at the front than the rear, swap round front wheels and rear wheels. Ensure that the direction of rotation of the wheels is the same as before.

Tyres age, even if they are not used. We recommend tyre replacement every 6 years.

Tyre chains



Tyre chains are only permitted on the front wheels.

Always use fine mesh chains that add no more than 10 mm to the tyre tread and the inboard sides (including chain lock).

⚠Warning

Damage may lead to tyre blowout.

Tyre repair kit

(if fitted)

Minor damage to the tyre tread or sidewall can be repaired with the tyre repair kit.

Do not remove foreign bodies from the tyres.

Tyre damage exceeding 4 mm or that is at tyre's side wall near the rim cannot be repaired with the tyre repair kit.

⚠Warning

Do not drive faster than 80 km/h.

Do not use for a lengthy period.

Steering and handling may be affected.

If you have a flat tyre:

Apply the parking brake and engage first gear, reverse gear or **P**.



The tyre repair kit is in a compartment under the floor cover in the load compartment.

1. Take the tyre repair kit from the compartment.
2. Remove the compressor.

30057

3. Remove the electrical connection cable and air hose from the stowage compartments on the underside of the compressor.


30058

4. Screw the compressor air hose to the connection on the sealant bottle.
5. Fit the sealant bottle into the retainer on the compressor.

   Set the compressor near the tyre in such a way that the sealant bottle is upright.


30059

6. Unscrew valve cap from defective tyre.
7. Screw the filler hose to the tyre valve.
8. The switch on the compressor must be set to O.
9. Connect the compressor plug to the accessory socket at the rear of the console.

   To avoid discharging the battery, we recommend running the engine.



10. Set the rocker switch on the compressor to **I**. The tyre is filled with sealant.
11. The compressor pressure gauge briefly indicates up to 90 PSI/620 kPa whilst the sealant bottle is emptying (approx. 30 seconds). Then the pressure starts to drop.
12. All of the sealant is pumped into the tyre. Then the tyre is inflated.
13. The recommended tyre pressure should be obtained within 10 minutes. Tyre pressure ⇨ 141. When the correct pressure is obtained, switch off the compressor.



If the recommended tyre pressure is not obtained within 10 minutes, remove the tyre repair kit. Move the vehicle one tyre rotation. Reattach the tyre repair kit and continue the filling procedure for 10 minutes.

⚠Warning

If the recommended pressure cannot be reached after approximately 10 minutes, the vehicle should not be driven. The tyre is too severly damaged and the tyre sealant and air compressor kit cannot inflate the tyre. Disconnect and stow the tyre sealant and air compressor kit back in its original position. Contact a Holden Dealer.

Drain excess tyre pressure with the button over the pressure indicator.

Do not run the compressor longer than 10 minutes.

14. Detach the tyre repair kit. Push catch on bracket to remove sealant bottle from bracket. Screw tyre inflation hose to free connection of sealant bottle. This prevents sealant from escaping. Stow tyre repair kit in load compartment.
15. Remove any excess sealant using a cloth.
16. Take the label indicating maximum permitted speed from the sealant bottle and affix in the driver's field of view.

17. Continue driving immediately so that sealant is evenly distributed in the tyre. After driving approx. 10 km (but no more than 10 minutes), stop and check tyre pressure. Screw compressor air hose directly onto tyre valve and compressor when doing this.


30062

If tyre pressure is more than 20 PSI/138 kPa, set it to the correct value. Repeat the procedure until there is no more loss of pressure.

If the tyre pressure has fallen below 20 PSI/138 kPa, the vehicle must not be used. Seek the assistance of your Holden Dealer.

18. Stow away tyre repair kit in load compartment.

Note

The driving comfort of the repaired tyre is severely affected, therefore have this tyre replaced.

If unusual noise is heard or the compressor becomes hot, turn compressor off for at least 30 minutes.

The built-in safety valve opens at a pressure of 100 PSI/690 kPa.

Note the expiry date of the kit. After this date its sealing capability is not longer guaranteed. Pay attention to storage information on sealant bottle.

Replace the used sealant bottle. Dispose of the bottle as prescribed by applicable laws.

The compressor and sealant can be used from approx. -30 °C.

The adapters supplied can be used to pump up other items e.g. footballs, air mattresses, inflatable dinghies etc. They are located on the underside of the compressor. To remove, screw on compressor air hose and withdraw adapter.

Wheel changing

Some vehicles are equipped with a tyre repair kit instead of a spare wheel ⇨ 143.

⚠Warning

All passengers must be out of the vehicle when it is being jacked.

Only jack the vehicle on hard, level surfaces.

Ensure moving parts of the jack are adequately lubricated before use.

Use the jack only at the designated lifting points. Use in other locations may cause the vehicle to fall off the jack, or may damage the vehicle.

If using a jack (or hoist) other than the jack supplied with the vehicle, refer to the following pages in this chapter for the correct lifting positions.

Do not start or run the engine while the vehicle is supported by the jack.

Use the jack only for lifting the vehicle when changing wheels.

Do not get under a vehicle that is supported by a jack. No person should place any portion of their body under a vehicle that is supported by a jack.

Vehicles with alloy wheels may have a steel spare wheel. Drive carefully and do not exceed 80 km/h when a combination of alloy and steel wheels are fitted on the vehicle. Although the spare tyre was fully inflated when the vehicle was new, it can lose air over time. Check the inflation pressure regularly. After installing the spare wheel on the vehicle, stop as soon as possible to check the inflation pressure is correct. Have the flat tyre repaired or replaced and installed back on the vehicle as soon as possible.

Make the following preparations and observe the following information:

- Park the vehicle on a level, firm and non-skid surface. The front wheels must be in the straight-ahead position.
- Apply the parking brake and engage first gear, reverse gear or **P**.
- Chock the wheel diagonally opposite the flat tyre with a suitable solid object.
- Remove the spare wheel and tools from inside the boot. The tools are located in the storage compartment underneath the spare wheel ⇨ 150.
- Never change more than one wheel at once.
- Use the jack only to change wheels in case of puncture.
- If the ground on which the vehicle is standing is soft, a solid board (max. 1 cm thick) should be placed under the jack.
- No people or animals may be in the vehicle when it is jacked-up.
- Never crawl under a jacked-up vehicle.
- Do not start the vehicle when it is raised on the jack.
- Clean wheel nuts and thread before replacing the wheel.

1. Remove nut caps, if fitted. The variant 2 wheel wrench has a tool on the end to assist.

2. Variant 1:

Install the wheel wrench ensuring that it locates securely and loosen each wheel nut by half a turn.

Variant 2:



Fold out the wheel wrench and install ensuring that it locates securely and loosen each wheel nut by half a turn.

3. If the sill panel has a cover:



Place hand behind the edge of the cover on the sill panelling.

Pull down and out to remove the cover. The cover is attached by a tether.



4. Ensure the jack is positioned correctly with the vehicle jacking points.
5. Variant 1:



Set the jack to the necessary height. Position it directly below the jacking point in a manner that prevents it from slipping.

Attach jack handle and with the jack correctly aligned rotate handle until wheel is clear of the ground.

Variant 2:



Set the jack to the necessary height. Position it directly below the jacking point in a manner that prevents it from slipping.

Attach wheel wrench and with the jack correctly aligned rotate wheel wrench until wheel is clear of the ground.

6. Unscrew the wheel nuts.
7. Change the wheel.
8. Screw on the wheel nuts.
9. Lower vehicle.
10. Install the wheel wrench ensuring that it locates securely and tighten each nut in a crosswise sequence.
11. Refit the nut caps, if fitted.
12. If the sill panel has a cover:



Reinstall cover.

Insert the two rear pins into the holes at the sill panelling and fold up the cover to engage.

13. Stow the replaced wheel ⇨ 150 and the vehicle tools ⇨ 140.
14. Check the tyre pressure of the installed tyre and also the wheel nut torque as soon as possible.

Have the defective tyre renewed or repaired.

⚠Warning

As soon as possible after changing a wheel, you should have the wheels tightened with a torque of 150 Newton metre and have the wheel balanced on the vehicle. Wheel bolts should be tightened evenly to the correct torque in a crisscross pattern while the vehicle is on the ground. Wheel bolts which have not been tightened properly could eventually allow the wheel to come off while the vehicle is moving.

Spare wheel

(if fitted)

The spare wheel is located in the boot beneath the floor covering. It is secured in the recess with a wing nut.

When replacing a wheel with the spare wheel, follow the appropriate steps to secure the removed wheel in the spare wheel well or boot:

Sportwagon with 16" or 17" alloy wheels and a 16" steel spare wheel

Stow in spare wheel well and secure with the wing nut.

Hatch with 17" or 18" alloy wheels and a space saver spare wheel

The removed wheel must be stowed in the load compartment and secured with a strap. Vehicle tools ⇨ 140.

1. Position the wheel close to one sidewall of the load compartment.



2. Place the loop end of the strap through the front lashing eye on the appropriate side.
3. Place the hook end of the strap through the loop and pull it until the strap is fastened securely to the lashing eye.

4. Insert the strap through the spokes of the wheel as shown in the illustration.
5. Mount the hook to the rear lashing eye.
6. Tighten the strap and secure it using the buckle.

⚠ Danger

Always drive with folded up and engaged rear seat backrests when stowing a damaged full size wheel in the load compartment.

Sedan with 17" or 18" alloy wheels and a space saver spare wheel

The removed wheel must be stowed in the spare wheel well and secured with the wing nut and LONG wheel tub stud. Vehicle tools ⇨ 140.

1. Loosen and remove the SHORT wheel tub stud using the socket located in the side of the wheel nut wrench.

2. Install the LONG wheel tub stud and tighten using the socket located in the side of the wheel nut wrench.

3. Remove the plastic spacer from the jack package and stow safely.
4. Install the jack package over the LONG wheel tub stud.
5. Install the removed alloy wheel over the LONG wheel tub stud.
6. Secure the removed alloy wheel using the wing nut.

Note that when stowing the space saver wheel, it is necessary to refit the SHORT wheel tub stud.

Temporary spare wheel

Caution

The use of a spare wheel that is smaller than the other wheels could affect driveability. Have the defective tyre replaced as soon as possible.

Only mount one temporary spare wheel. Do not drive faster than 80 km/h. Take curves slowly. Do not use for a long period of time.

Directional tyres

Fit directional tyres such that they roll in the direction of travel. The rolling direction is indicated by a symbol (e.g. an arrow) on the sidewall.

The following applies to tyres fitted opposing the rolling direction:

- Driveability may be affected. Have the defective tyre renewed or repaired as soon as possible.
- Do not drive faster than 80 km/h.
- Drive particularly carefully on wet and snow-covered road surfaces.

Jump starting

Do not start with quick charger.

A vehicle with a discharged battery can be started using jump leads and the battery of another vehicle.

⚠Warning

Be extremely careful when starting with jump leads. Any deviation from the following instructions can lead to injuries or damage caused by battery explosion or damage to the electrical systems of both vehicles.

⚠Warning

Avoid contact with eyes, skin, fabrics and painted surfaces. The fluid contains sulphuric acid which can cause injuries and damage in the event of direct contact.

⚠ Warning

Never expose the battery to naked flames or sparks.

Wear eye protection and protective clothing when handling a battery.

Do not lean over the battery during jump starting.

Do not allow the terminals of one lead to touch those of the other lead.

- A discharged battery can already freeze at temperatures of 0 °C. Defrost the frozen battery before connecting jump leads.
- Use a booster battery with the same voltage (12 volts). Its capacity (Ah) must not be much less than that of the discharged battery.
- Use jump leads with insulated terminals and a cross section of at least 16 mm^2.
- Do not disconnect the discharged battery from the vehicle.
- Switch off all unnecessary electrical consumers.
- The vehicles must not come into contact with each other during the jump starting process.
- Apply the parking brake, transmission in neutral, automatic transmission in **P**.
- Open the positive terminal protection caps of both batteries.



Lead connection order:

1. Connect the red lead to the positive terminal of the booster battery.
2. Connect the other end of the red lead to the positive terminal of the discharged battery.
3. Connect the black lead to the negative terminal of the booster battery.
4. Connect the other end of the black lead to a vehicle grounding point, such as the engine block or an engine mounting bolt. Connect as far away from the discharged battery as possible.

Route the leads so that they cannot catch on rotating parts in the engine compartment.

To start the engine:

1. Start the engine of the vehicle providing the jump.
2. After 5 minutes, start the other engine. Start attempts should be made for no longer than 15 seconds at intervals of 1 minute.

3. Allow both engines to idle for approx. 3 minutes with the leads connected.
4. Switch on electrical consumers (e.g. headlights, heated rear window) of the vehicle receiving the jump start.
5. Reverse above sequence exactly when removing leads.

Towing

Towing the vehicle

Disengage cap at bottom of front fascia by inserting a suitable tool in the slot.

The towing eye is stowed with the vehicle tools ⇨ 140.



Screw in the towing eye as far as it will go until it stops in a horizontal position.

Attach a tow rope to the towing eye.

The towing eye must only be used for towing and not for recovering the vehicle.

Switch on ignition to release steering column lock and to permit operation of brake lights, horn and windscreen wipers.

Transmission in neutral.

Caution
Drive slowly. Excessive force can damage the vehicle.

When the engine is not running, considerably more force is needed to brake and steer.

To prevent the entry of exhaust fumes from the towing vehicle, switch on the air recirculation and close the windows.

Vehicles with automatic transmission: The vehicle must be towed facing forwards, not faster than 80 km/h nor further than 100 km. In all other cases and when the transmission is defective, the front axle must be raised off the ground.

Seek the assistance of your Holden Dealer.

After towing, unscrew the towing eye and replace cap.

The best method is to have the vehicle transported using a recovery vehicle.

Appearance care

Exterior care

Washing

The paintwork of your vehicle is exposed to environmental influences. Wash and wax your vehicle regularly. When using automatic vehicle washes, select a programme that includes waxing.

Bird droppings, dead insects, resin, pollen and the like should be cleaned off immediately, as they contain aggressive constituents which can cause paint damage. Failure to do so may result in permanent damage, particularly in hot weather conditions.

Road bloom is a gradual build up of road and environmental grime. This should be removed with a paint cleaner product, in addition to normal washing, on an annual basis.

If using a vehicle wash, comply with the vehicle wash manufacturer's instructions. Never use an automatic wash that requires anything touching the paint (other than water).The windscreen wipers and rear window wiper must be switched off.

Remove antenna and external accessories such as roof racks etc.



To remove the roof antenna, rotate it anti-clockwise. To install the roof antenna, rotate it clockwise.

If you wash your vehicle by hand, make sure that the insides of the wheel housings are also thoroughly rinsed out.

Clean edges and folds on opened doors and the bonnet, as well as the areas they cover.

Caution

Always use a cleaning agent with a pH value of 4 to 9.

Do not use cleaning agents on hot surfaces.

Have the door hinges of all doors greased by your Holden Dealer.

⚠Warning

Do not clean the engine compartment with a steam-jet or high-pressure jet cleaner.

Thoroughly rinse and chamois off the vehicle. Rinse chamois frequently. Use a separate chamois for painted and glass surfaces: remnants of wax on the windows will impair vision.

Do not use hard objects to remove spots of tar. Use tar removal spray on painted surfaces.

Exterior lights

Headlight and other light covers are made of plastic. Do not use any abrasive, solvent based cleaners or caustic agents and do not clean them dry.

Polishing and waxing

Wax the vehicle regularly (at the latest when water no longer beads).

Polishing is necessary only if the paint has become dull or if solid deposits have become attached to it.

Paintwork polish with silicone forms a protective film, making waxing unnecessary.

Plastic body parts must not be treated with wax or polishing agents.

Windows and windscreen wiper blades

Use a soft lint-free cloth or chamois leather together with window cleaner and insect remover.

When cleaning the rear window from inside, always wipe in parallel to the heating element to prevent damage.

Clean smearing wiper blades with a soft cloth and window cleaner.

Wheels and tyres

Do not use high-pressure jet cleaners.

Clean rims with a pH-neutral wheel cleaner.

Rims are painted and can be treated with the same agents as the body.

Paintwork damage

Rectify minor paintwork damage with a touch-up pen before rust forms. Have more extensive damage or rust areas repaired by your Holden Dealer.

Underbody

Some areas of the vehicle underbody have a PVC undercoating while other critical areas have a durable protective wax coating.

After the underbody is washed, check the underbody and have it waxed if necessary.

Bitumen/rubber materials could damage the PVC coating. Have underbody work carried out by your Holden Dealer.

Interior care

Interior and upholstery

Only clean the vehicle interior, including the instrument panel fascia and panelling, with a dry cloth or interior cleaner.

The instrument cluster and the displays should only be cleaned using a soft damp cloth. If necessary use a weak soap solution.

Clean fabric upholstery with a vacuum cleaner and brush. Remove stains with an upholstery cleaner.

Clothing fabrics may not be colourfast. This could cause visible discolourations, especially on light-coloured upholstery. Removable stains and discolourations should be cleaned as soon as possible.

Clean seat belts with lukewarm water or interior cleaner.

Caution

Close Velcro fasteners as open Velcro fasteners on clothing could damage seat upholstery.

Leather

Clean regularly using a leather revitaliser or mild detergent.

- Apply revitaliser using a lint free cloth and rub it onto the leather.
- Do not saturate the leather with the cleaner and do not pour on directly.
- Allow to dry naturally.
- For deeply embedded soil and dirt, use a leather cleaner.
- After using a leather cleaner/ revitaliser, apply a leather protector.

  A leather protector is designed to repel dirt and provides water resistance.

Note

- Clean and protect leather at least twice a year.
- Do not use synthetic cloths or brushes.
- Leather is a natural product and may have natural markings or variations in graining, colouring and wrinkling.
- Leather has an elasticity and may stretch. This is a natural characteristic of leather.

Plastic and rubber parts

Plastic and rubber parts can be cleaned with the same cleaner as used to clean the body of the vehicle. Use interior cleaner if necessary. Do not use any other agent. Avoid solvents and petrol in particular. Do not use high-pressure jet cleaners.

Service and maintenance

General information 158
Recommended fluids, lubricants and parts 158

General information

Service information

In order to ensure economical and safe vehicle operation and to maintain the value of your vehicle, it is of vital importance that all maintenance work is carried out at the proper intervals as specified.

See your Service booklet for the service schedules and for more information.

Recommended fluids, lubricants and parts

Recommended fluids and lubricants

Only use products that meet the recommended specifications. Damage resulting from the use of products not in line with these specifiations will not be covered by the warranty.

⚠Warning

Operating materials are hazardous and could be poisonous. Handle with care. Pay attention to information given on the containers.

Engine oil

Engine oil is identified by its quality and its viscosity. Quality is more important than viscosity when selecting which engine oil to use. The oil quality ensures e.g. engine cleanliness, wear protection and oil aging control, whereas viscosity grade gives information on the oil's thickness over a temperature range.

Engine oil quality

dexos 1 = 1.6L Petrol engine, 1.8L Petrol engine

Selecting the right engine oil

Selecting the right engine oil depends on the proper oil specification and viscosity grade.

Use and ask for engine oils with the dexos certification mark. Oils meeting the requirements of your vehicle should have the dexos certification mark on the container. This certification mark indicates that the oil has been approved to the dexos specification.

Your vehicle was filled at the factory with dexos approved engine oil.

Use only engine oil that is approved to the dexos specification or an equivalent engine oil of the appropriate viscosity grade.

If you are unsure whether your oil is approved to the dexos specification, ask your service provider.

Use of substitute engine oils if dexos is unavailable: In the event that dexos approved engine oil is not available at an oil change or for maintaining proper oil level, you may use substitute engine oil of the qualities mentioned above. Use of oils that do not meet the dexos specification, however, may result in reduced performance or engine damage under certain circumstances.

Topping up engine oil

Engine oils of different manufacturers and brands can be mixed as long as they comply with the required engine oil (quality and viscosity).

Engine oil additives

The use of engine oil additives could cause damage and invalidate the warranty.

Engine oil viscosity grades



SAE 5W-30 is the best viscosity grade for your vehicle. Do not use other viscosity grade oils such as SAE 10W-30, 10W-40 or 20W-50.

For acceptable alternative viscosity grade oils ⇨ 164.

When selecting an oil of the appropriate viscosity grade be sure to always select an oil that meets the dexos specification.

The SAE viscosity grade gives information of the thickness of the oil. Multigrade oil is indicated by two figures.

The first figure, followed by a W, indicates the low temperature viscosity and the second figure the high temperature viscosity.

Coolant and antifreeze

Use only silicate-free long life coolant (LLC) antifreeze.

The system is factory filled with coolant designed for excellent corrosion protection and frost protection down to approx. -38 °C. This concentration should be maintained all year round. The use of additional coolant additives that intend to give additional corrosion protection or seal against minor leaks can cause function problems. Liability for consequences resulting from the use of additional coolant additives will be rejected.

Brake and clutch fluid

Only use DOT4 brake fluid.

Over time, brake fluid absorbs moisture which will reduce braking effectiveness. The brake fluid should therefore be replaced at the specified interval.

Brake fluid should be stored in a sealed container to avoid water absorption.

Ensure brake fluid does not become contaminated.

⚠Warning

Using brake fluid other than GM recommended brake fluid may cause corrosion to components of the braking system and reduced braking performance.

Use only new brake fluid. Use of old, used or inferior brake fluid may endanger the functioning of the brake system.

Power steering fluid

Only use Dexron VI fluid.

Automatic transmission fluid

Only use Dexron VI fluid.

Technical data

Vehicle identification 161
Vehicle data 164

Vehicle identification

Vehicle Identification Number

The Vehicle Identification Number is visible through the windscreen.

A further label is located in the vehicle floor on the right-hand side under a cover between the front door and seat.

Identification plate



An identification label is located on the front left door frame.



Information on identification label:

1 = Approval number
2 = Manufacturer
3 = Category
4 = Number of seats
5 = Vehicle identification number
6 = Compliance date



A further identification plate is located under the bonnet on the dash panel.



Information on identification plate:

1 = Manufacturer
2 = Body color
3 = Build date
4 = Vehicle identification number

Engine serial number

1.6L Petrol engine



The engine serial number is located in the front part of the engine compartment.

1.8L Petrol engine



The engine serial number is located next to the oil filter.

Vehicle data

Recommended fluids and lubricants

Manufacturer's specifications

Engine oil specification

	Engine oil specification	Best viscosity grade for the vehicle	Alternative viscosity
1.6L Petrol	dexos 1	5W-30	0W-30
1.8L Petrol	dexos 1	5W-30	0W-30

Fluids/Lubricants

Usage	Fluid/Lubricant
Coolant specification	50% clean water and 50% Dexcool anti-freeze coolant, conforming to specification number GM6277M
Brake & clutch fluid	DOT 4 Hydraulic brake fluid, conforming to specification number GMW 3356
Power steering fluid	Dexron - VI Auto trans fluid
Automatic transmission fluid	Dexron - VI Auto trans fluid
Manual transmission fluid	1.6L Petrol: GM Part Number 93165694 (BOT303, Low Viscosity 70W)
	1.8L Petrol: SAE 75W-90

Engine data

Engine	1.6L Petrol	1.8L Petrol
Number of cylinders	4	4
Piston displacement [cm^3]	1598	1796
Engine power [kW] at rpm	Refer to holden. com.au	
Torque [Nm] at rpm	Refer to holden. com.au	
Fuel type	Petrol	Petrol
Octane rating RON		
Minimum	91	91
Recommended	95	91

Vehicle weight

Additional weight

Maximum vehicle payloads

Vehicle	Occupants (Average 68 kg each)	Luggage (kg)	Total Load (kg)
4 Door sedan	5	68	408
5 Door hatchback	5	68	408
Sportwagon	5	68	408

Maximum front and rear axle loads

Vehicle	Front axle loads (kg)	Rear axle loads (kg)
1.6L Petrol	1160	1000
1.8L Petrol	1060	1000

Vehicle dimensions

4 Door sedan

	CD/EQUIPE/CDX	SRi/SRi-V
Length [mm]	4615	4629
Width without exterior mirrors [mm]	1797	1797
Height (without antenna) [mm]	1477	1477
Wheelbase [mm]	2685	2685

5 Door hatchback

	CD/EQUIPE/CDX	SRi/SRi-V
Length [mm]	4519	4543
Width without exterior mirrors [mm]	1797	1797
Height (without antenna) [mm]	1477	1477
Wheelbase [mm]	2685	2685

Sportwagon

	CD/CDX
Length [mm]	4675
Width without exterior mirrors [mm]	1797
Height (without antenna) [mm]	1521
Wheelbase [mm]	2685

Capacities

Engine oil

Engine	1.6L Petrol	1.8L Petrol
including Filter [l]	4.5	4.5

Engine coolant

Engine	1.6L Petrol	1.8L Petrol
capacity [l]	6.5	6.5

Fuel tank

Petrol, nominal capacity [l]	60

Tyre pressures

4 Door sedan, 5 Door hatchback

Tyre size Wheel size and profile	Recommended pressure													
	Normal load				Eco normal load				Maximum load				Spare	
	Front		Rear		Front		Rear		Front		Rear		–	
	kPa	PSI	kPa	PSI	kPa	PSI	kPa	PSI	kPa	PSI	kPa	PSI	kPa	PSI
215/50 R17 91V 17 x 7.0, J	250	36	250	36	270	39	270	39	270	39	300	44	–	–
225/50 R17 94V 17 x 7.0 , J	250	36	250	36	270	39	270	39	270	39	300	44	–	–
235/45 R18 94 V 18 x 8.0 , J	250	36	250	36	270	39	270	39	270	39	270	39	–	–
T115/70 R16 92M 16 x 4.0 , J	–	–	–	–	–	–	–	–	–	–	–	–	420	61

Sportwagon

Tyre size Wheel size and profile	Recommended pressure													
	Normal load				Eco normal load				Maximum load				Spare	
	Front		Rear		Front		Rear		Front		Rear		–	
	kPa	PSI	kPa	PSI	kPa	PSI	kPa	PSI	kPa	PSI	kPa	PSI	kPa	PSI
205/60 R16 92V 16 x 6.5 , J	250	36	250	36	270	39	270	39	270	39	300	44	–	–
215/50 R17 91V 17 x 7.0 , J	250	36	250	36	270	39	270	39	270	39	300	44	–	–
225/50 R17 94V 17 x 7.0 , J	250	36	250	36	270	39	270	39	270	39	300	44	–	–
205/60 R16 98N 16 x 6.5 , J	–	–	–	–	–	–	–	–	–	–	–	–	300	44

Customer information

Customer information 172

Customer information

Owner assistance

Holden Customer Care

At Holden, we want you to be completely satisfied with your ownership experience. This applies to your vehicle and any Holden representative you may deal with. Refer below for two options for seeking assistance with your query.

Holden Dealerships

Holden encourages you to seek assistance from your Holden Dealership. Each Holden Dealership is equipped to manage any sales, servicing, parts or technical query. In the instance that you wish to escalate a query to a higher level of staff, further options are available to you. As a first step, Holden suggests you discuss any concern with the relevant Department Manager (Sales Manager or Service Manager). Alternatively, the Dealership General Manager or Dealer Principal will also be happy to assist you.

Holden Customer Care Office

Should you wish to speak to a Holden representative, you are welcome to contact the Holden Customer Care team. Refer below for operating hours and various methods of communication.

Operating Hours

Weekdays: 8am - 7pm AEST

Saturday: 9am - 1pm AEST

Telephone

Holden Customer Care can be telephoned from anywhere within Australia for only the cost of a local call.

The contact number is:

1800 033 349

Email

Alternatively, you may prefer to email Holden at:

holdencustomercare@gm.com

Written Correspondence

You can also write to Holden at the address below:

The Manager

Holden Customer Care Centre

GPO Box 1714

Melbourne 3001

Your written correspondence should clearly outline your concern or query and include:

- Your name and address
- Telephone numbers, both private and business
- Servicing dealer's name and address
- Vehicle model
- Vehicle identification number (I.S.O.V.I.N.), refer to the inside front cover of the Service/ Warranty Booklet in your vehicle's glove box
- Date of purchase
- Current odometer reading

Most of this information will be found on the Vehicle Identification Certificate, located inside the front cover of the Service/Warranty Booklet in your vehicle's glove box.

Before you write however, remember that the telephone is the quicker and more efficient means of communication.

New Zealand

The information in this Owner's Handbook applies primarily to Australian Holden vehicles and there may be some differences to the Warranty and Owner Assistance provisions for New Zealand.

Applicable details for New Zealand are set out in the Holden Warranty and Owner Assistance Information booklet enclosed in the New Zealand glove box wallet.

New Zealand Assistance can be reached on:

0800 HOLDEN (0800 465 336)

This number provides access to New Zealand Roadside Assistance as well as New Zealand Customer Care.

Alternatively, you may prefer to email Holden at:

holdencustomercare@gm.com

You can also write to Holden at the address below:

The Manager

Holden Customer Care Centre

P.O. Box 11195

Ellerslie

Auckland 1542

New Zealand

Index

A

Accessories and vehicle modifications 118
Adjustable air vents 90
Airbag and belt tensioners 67
Airbag system 42
Air conditioning regular operation 91
Air conditioning system 84
Air intake 91
Antilock brake system 103
Antilock brake system (ABS) 68
Anti-theft alarm system 27
Apply footbrake 70
Armrest 37, 38
Armrest storage 52
Automatic Door Locks 25
Automatic light control 79
Automatic transmission 98

B

Battery discharge protection 83
Bonnet 119
Boot 26
Brake and clutch fluid..... 158
Brake and clutch system 68
Brake assist 104
Brake fluid 126
Brakes 103
Bulb replacement 127

C

Capacities 169
Catalytic converter 98
Central locking system 22
Charging system 67
Child locks 25
Child restraint installation locations 48
Child restraint systems 45
Climate control 14
Clock..... 62
Colour Information Display (CID).. 72
Control indicators..... 65
Control of the vehicle 93
Convex Mirrors 29
Coolant and antifreeze..... 158
Cruise control 70, 106
Cupholders 51
Curtain airbag system 44

D

Danger, Warnings and Cautions ... 3
Daytime running lights 80
Door Ajar Light 70
Driver Information Centre..... 71

E

Electronic climate control system 86
Electronic driving programmes .. 100
Electronic key system..... 20

Electronic Stability Control . . 69, 105
Electronic Stability Control off 69
Engine air filter..... 124
Engine compartment fuse box ... 137
Engine compartment overview... 121
Engine coolant 124
Engine data 165
Engine exhaust 98
Engine oil 123, 158
Engine oil pressure 69
Engine Temperature gauge 65
Entry lighting 83
Exit lighting 83
Exterior care 155
Exterior light 70
Exterior lighting 11

F
Fault 101
Fixed air vents 91
Fog light 70
Fog lights 129
Folding Mirrors 29
Footbrake..... 70
Front airbag system 42
Front fog lights 81
Fuel for petrol engines 110
Fuel gauge 65
Fuses 136

G
General information 112
Glovebox 51

H
Halogen headlights 127
Hand brake..... 103
Hazard warning flashers 80
Headlight flash 80
Head restraint adjustment 6
Head restraints 34
Heated Front Seats 37
Heated mirrors 30
Heated rear window 32
High beam 70, 80
Horn 12, 60

I
Identification plate 162
Ignition switch positions 94
Immobiliser 28, 70
Instrument panel fuse box 139
Instrument panel illumination 135
Instrument panel illumination control 82
Instrument panel overview 9
Instrument panel storage..... 50
Interior care 157
Interior lights 82, 135
Interruption of power supply 101
Introduction 3
Isofix child restraint systems 49

J
Jack..... 146
Jump starting 152

K
Keys 19

L
Lashing eyes 56
Light switch 79
Load compartment 52
Load compartment cover 54
Loading information 58
Low fuel 70

M
Malfunction Indicator Lamp 68
Manual mode 100
Manual Rearview Mirror 30
Manual transmission 102
Mirror adjustment 7
Misted light covers 81

N
New vehicle running-In 93
Number plate light 134

O
Odometer 64
Outside temperature 62
Overrun cut-off 97
Owner assistance..... 172

P
Parking 17, 97
Parking assist 107
Parking brake 103
Performing work 119
Pollen filter 91
Power Mirrors 29
Power outlets 63
Power steering..... 68
Power steering fluid..... 125
Power windows 31

R
Reading lights 82
Rear floor storage cover 55
Rear storage..... 53
Rear view camera 108
Rear window wiper/washer 61
Recommended fluids and lubricants 158, 164
Refuelling 111
Remote control 19
Remote engine start..... 94
Reversing lights 81
Roof load..... 58
Roof rack 57

S
Safety net 56
Seat adjustment 5, 36
Seat belt 7
Seat belt reminder 67
Seat belts 38
Seat position 35
Service 91, 158
Service information 158
Service vehicle soon 68
Shift lever 99
Side airbag system 43
Side turn signal lights 134
Spare wheel 150
Speedometer 64
Sport mode..... 99
Starting off 16
Starting the engine 94
Steering wheel adjustment 8, 59
Steering wheel controls 59
Storage compartments..... 50
Sunglasses storage 52
Sun visors 33
Symbols 3

T
Tachometer 64
Tail lights 129
Three-point seat belt 40
Tools 140
Top-tether child restraint systems 49
Tow bar..... 112
Towing the vehicle 154
Traction control system 104
Traction Control system off 69
Trailer towing 113
Transmission 15
Transmission display 98
Tread depth 142
Trip computer 74
Trip odometer 64
Turn and lane-change signals 81
Turn signal 67
Tyre chains 143
Tyre pressure 141
Tyre pressures 170
Tyre repair kit 143

U
Ultrasonic parking assist 69
Unlocking..... 4
Upholstery..... 157
Using this manual 3

V

Vehicle battery 126
Vehicle dimensions 167
Vehicle Identification Number 161
Vehicle messages 73
Vehicle personalisation 76
Vehicle storage..... 118
Vehicle unlocking 4
Vehicle weight 166

W

Warning chimes 74
Washer and wiper systems 13
Washer fluid 126
Wheel changing 146
Wheels and tyres 141
Windscreen wiper/washer 60
Wiper blade replacement 127